

SERVICE MANUAL

AA-2W CHASSIS

<u>MODEL</u>	<u>DEST.</u>	<u>COMMANDER</u>	<u>CHASSIS NO.</u>
KV-27FV15	U.S.	RM-Y171	SCC-S32A-A
KV-27FV15	CND	RM-Y171	SCC-S33A-A
KV-29FV10	E	RM-Y168	SCC-S34D-A
KV-29FV15	E	RM-Y171	SCC-S34A-A
KV-29FV15C	E	RM-Y171	SCC-S34C-A
KV-29FV15K	KOREA	RM-Y149A	SCC-S31A-A



KV-29FV15



RM-Y171



TRINITRON® COLOR TV
SONY®

SPECIFICATIONS

	All Models Except KV-29FV10	KV-29FV10
Power requirements	120V, 60Hz (KV-27FV15 Only); Auto Volt	Auto Volt
Number of inputs/outputs:		
Video ¹⁾	3	3
S Video ²⁾	2	2
Audio ³⁾	3	3
Audio Out ⁴⁾	1	1
Monitor Out	1	1
TV Out ^{1) 3)}	1	—
S-Link	2	—
RF Input	2	1
Speaker output (W)	15W x 2	15W x 2
Power Consumption (W):		
In use (max.)	165W	155W
In standby	2W	2W
Dimensions (W/H/D):		
(mm)	762 x 604 x 499 mm	762 x 604 x 499 mm
(in.)	30 x 23 ^{3/4} x 19 ^{5/8} in	30 x 23 ^{3/4} x 19 ^{5/8} in
Mass:		
(kg.)	50 kg	50 kg
(lbs.)	110 lbs	110 lbs

Television system

American TV standard (KV-27FV15), NTSC

Channel coverage

VHF:2-13 / UHF:14-69 / CATV:1-125

Picture tube

FD Trinitron® tube

Visible screen size

27-inch picture measured diagonally

Actual screen size

29-inch picture measured diagonally

Antenna

75 ohm external antenna terminal for VHF/UHF

Supplied accessories

Remote control RM-Y168 (KV-29FV10)
 Remote control RM-Y171 (All Models Except
 KV-29FV10, KV-29FV15K)
 Remote Control RM-Y149A (KV-29FV15K)
 Battery size AA (R6) w/2

Optional accessories

Connecting Cables:
 RK-74A, RK-G69HG
 VMC-10HG/30HG, VMC-720M,
 VMC-810S/820S, YC-15V/30V,
 TV Stand: SU-27A3
 VHF/UHF Mixer: EAC-66

Notes:¹⁾ 1 Vp-p 75 ohms unbalanced, sync negative²⁾ Y: 1 Vp-p 75 ohms unbalanced, sync negative

C: 0.286 Vp-p (Burst signal), 75 ohms

³⁾ 500 mVrms (100% modulation), Impedance: 47 kilohms⁴⁾ More than 408 mVrms at the maximum volume setting (variable)

More than 408 mVrms (fix); Impedance (Output): 2 kilohms

(●)® SRS (SOUND RETRIEVAL SYSTEM)

The (●) SRS (SOUND RETRIEVAL SYSTEM) is manufactured by Sony Corporation under license from SRS Labs, Inc. It is covered by U.S. Patent No. 4,748,669. Other U.S. and foreign patents pending.

The word 'SRS' and the SRS symbol (●) are registered trademarks of SRS Labs, Inc.

BBE and BBE symbol are trademarks of BBE Sound, Inc. and are licensed by BBE Sound, Inc. under U.S. Patent No. 4,638,258 and 4,482,866.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
Warnings and Caution	3		6. DIAGRAMS	6-1. Block Diagram (1/3)	31
Safety Check Out Instructions	4			6-2. Block Diagram (2/3)	34
1. GENERAL				6-3. Block Diagram (PIP 3/3)	37
Connecting and Installing the TV	5			6-4. Circuit Boards Location	38
Basic Set Up	7			6-5. Printed Wiring Boards and Schematic Diagrams	38
Using Your TV	7			• A Board	39
Using Your Menus	8			• A Board Schematic Diagram	41
Operating Video Equipment	11			• AK Board	45
Operating a Cable Box or DBS Receiver	12			• C Board	49
Troubleshooting	12			• G Board	51
2. DISASSEMBLY				• GA Board	53
2-1. Rear Cover Removal	13			• HA Board	53
2-2. Chassis Assembly Removal	13			• HB Board	54
2-3. Service Position	14			• HX Board	55
2-4. Multi-Button Switch Removal.....	14			• UY Main Board	57
2-5. Picture Tube Removal	15			• UY PIP Board	61
3. SET-UP ADJUSTMENTS				• WA Board	63
3-1. Beam Landing	16			6-6. Semiconductors	65
3-2. Convergence	17		7. EXPLODED VIEWS		
3-3. Focus	18		7-1. Chassis	66	
3-4. Screen (G2)	18		7-2. Picture Tube	67	
3-5. White Balance Adjustments	19				
4. SAFETY RELATED ADJUSTMENTS	20		8. ELECTRICAL PARTS LIST		
5. CIRCUIT ADJUSTMENTS	21		• Parts Listings	69	
5-1. Electrical Adjustment by Remote Commander	21				

WARNINGS AND CAUTIONS

CAUTION!

AFTER REMOVING THE ANODE, SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT.

WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS. THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL FOR SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL FOR SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

ATTENTION!

APRES AVOIR DECONNECTE LE CAP DE L'ANODE, COURT-CIRCUITER L'ANODE DU TUBE CATHODIQUE ET CELUI DE L'ANODE DU CAP AU CHASSIS METALLIQUE DE L'APPAREIL, OU AU COUCHE DE CARBONE PEINTE SUR LE TUBE CATHODIQUE OU AU BLINDAGE DU TUBE CATHODIQUE.

ATTENTION!!

AFIN D'EVITER TOUT RESQUE D'ELECTROCUTION PROVENANT D'UN CHASSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISE LORS DE TOUT DEPANNAGE. LE CHASSIS DE CE RECEPTEUR EST DIRECTEMENT RACCORDE A L'ALIMENTATION SECTEUR.

ATTENTION AUX COMPOSANTS RELATIFS A LA SECURITE!!

LES COMPOSANTS IDENTIFIES PAR UNE TRAME ET PAR UNE MARQUE  SUR LES SCHEMAS DE PRINCIPE, LES VUES EXPLOSEES ET LES LISTES DE PIECES SONT D'UNE IMPORTANCE CRITIQUE POUR LA SECURITE DU FONCTIONNEMENT. NE LES remplacer que par des composants Sony dont le numero de piece est indique dans le present manuel ou dans des supplements publies par Sony. Les reglages de circuit dont l'importance est critique pour la securite du fonctionnement sont identifies dans le present manuel. suivre ces procedures lors de chaque remplacement de composants critiques, ou lorsqu'un mauvais fonctionnement suspecte.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the B+ and HV to see if they are specified values. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
8. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC Leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampere). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instructions.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low voltage scale. The Simpson's 250 and Sanwa SH-63Trd are examples of passive VOMs that are suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-100 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)




Fig. A. Using an AC voltmeter to check AC leakage.




Fig. B. Checking for earth ground.

SECTION 1 GENERAL

The instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers shown reflect those of the Operating Instruction Manual.

Connecting and Installing the TV

Making Connections

Refer to the table below, it will direct you to the diagram suitable to the equipment you will be connecting.


If you will be connecting	See page
Cable or antenna only	3
Cable and antenna	3
Cable box	4
Cable box and cable to view scrambled channels	4
VCR and cable or antenna	4
VCR and cable box	5
Two VCRs for tape editing	6
Satellite Receiver	7
VCR and Satellite Receiver	7
DVD Player	8
DVD Player with component video output connectors	8
Audio system	9
Camcorder to view tapes	9
CONTROLS	10
VCR using S-Link	11
Satellite Receiver using S-Link	11

Cable and antenna

If your cable provider does not feature local channels, you may find this set up convenient.



CATV cable



(Rear of TV)
TO CONVERTER
Antenna cable



VHF/UHF
Antenna connector

Note

In order to receive channels with an antenna, you will need to turn your CABLE to OFF and perform the AUTO PROGRAM function, (see page 23).

Cable or Antenna Connections

Connecting directly to cable or an antenna

The connection you choose will depend on the cable found in your home. Newer homes will be equipped with standard coaxial cable (see A), older homes will probably have 300-ohm twin lead cable (see B); still other homes may contain both (see C).

Note

Select CABLE or antenna (ANT) mode by pressing ANT on the remote control.

A

VHF only
or
UHF
or
Cable

75-ohm
coaxial cable

(Rear of TV)
VHF/UHF

B

VHF only
or
UHF only
or
VHF/UHF

300-ohm twin
lead cable

(Rear of TV)
VHF/UHF

C

VHF
or
UHF

75-ohm coaxial cable

(Rear of TV)
VHF/UHF

Note

In order to receive channels with an antenna, you will need to turn your CABLE to OFF and perform the AUTO PROGRAM function, (see page 23).

— 5 —

Connecting and Installing the TV (continued)

VCR Connections

Connecting an antenna/cable TV system with a VCR

- 1 Attach the coaxial connector from your cable or antenna to IN on your VCR.
- 2 Using A/V connectors, connect AUDIO and VIDEO OUT on your VCR to AUDIO and VIDEO IN on your TV.
- 3 Using a coaxial connector, connect OUT on your VCR to VHF/UHF on your TV.

Tip If you are connecting a manual VCR, connect only the single audio output to the left input on your TV.

Connecting a VCR and TV with a cable box

- 1 Connect the coaxial cable from the wall to IN on your cable box.
- 2 Using a coaxial connector, connect OUT on your cable box to IN on your VCR.
- 3 Connect a coaxial cable (not supplied) from the OUT jack on your VCR to VHF/UHF on your TV.
- 4 Using A/V connectors, connect AUDIO and VIDEO OUT on your VCR to AUDIO and VIDEO IN on your TV.

Cable box and cable

- For this set up, you can switch between scrambled channels (through your cable box) and normal (CATV) channels by pressing ANT on your remote control.
- Your Sony remote control can be programmed to operate your cable box, (see page 31).
 - When using PIP, you cannot view the AUX Input in the window picture.

Notes

- Pressing ANT switches between these inputs.
- 4

Cable box

- If you are connecting a cable box through the AUX input and would like to switch between the AUX and normal (CATV) input, you should consider using the CHANNEL FIX feature, (see page 23).

Tip If you are connecting a cable box to the left input on your TV, connect only the single audio output to the left input on your TV.

Cable box and cable

- 1 Connect the coaxial cable from the wall to IN on your cable box.
- 2 Using a coaxial connector, connect OUT on your cable box to IN on your VCR.
- 3 Connect a coaxial cable (not supplied) from the OUT jack on your VCR to VHF/UHF on your TV.
- 4 Using A/V connectors, connect AUDIO and VIDEO OUT on your VCR to AUDIO and VIDEO IN on your TV.

Note

In order to receive channels with an antenna, you will need to turn your CABLE to OFF and perform the AUTO PROGRAM function, (see page 23).

Tip If you are connecting a manual VCR, connect only the single audio output to the left input on your TV.

Tip If you are connecting a cable box to the left input on your TV, connect only the single audio output to the left input on your TV.

Cable and antenna

If your cable provider does not feature local channels, you may find this set up convenient.

Tip If you are connecting a cable box to the left input on your TV, connect only the single audio output to the left input on your TV.

Tip If you are connecting a cable box to the left input on your TV, connect only the single audio output to the left input on your TV.

Connecting and Installing the TV (continued)

Connecting two VCRs for tape editing


MONITOR OUT gives you the ability to use a second VCR to record a program being played by the primary VCR or to perform tape editing and dubbing.

- 1 Connect the VCR intended for playback using the connection instructions on page 5 of this manual.
- 2 Using A/V connectors, connect AUDIO and VIDEO IN on your VCR intended for recording to MONITOR AUDIO and VIDEO OUT on your TV.

Note

You cannot record signals from equipment connected to the Y, Pb, Pr input.

To perform tape editing, set the TV to the video input intended for playback by pressing TV/VIDEO.



6

Satellite Receiver Connections



Connecting a satellite receiver

- 1 Connect the cable from your satellite antenna to SATELLITE IN on your receiver.
- 2 Attach the coaxial connector from your cable or antenna to VHF/UHF on your TV.
- 3 Using A/V connectors, connect AUDIO and VIDEO OUT on your receiver to AUDIO and VIDEO IN on your TV.

Connecting a satellite receiver and a VCR

- 1 Connect the cable from your satellite antenna to SATELLITE IN on your receiver.
- 2 Attach the coaxial connector from your cable or antenna to IN on your VCR.
- 3 Using a coaxial connector, connect OUT on your VCR to VHF/UHF on your TV.
- 4 Using A/V connectors, connect AUDIO and VIDEO OUT on your receiver to AUDIO and VIDEO IN on your VCR.
- 5 Using A/V connectors, connect AUDIO and VIDEO OUT on your VCR to AUDIO and VIDEO IN on your TV.

For optimum picture quality use S VIDEO instead of composite video. If you do not have S VIDEO connectors, you must still be connected.



7

Connecting and Installing the TV (continued)

DVD Player Connections

Connecting a DVD player

- 1 Using audio connectors, connect AUDIO OUT on your DVD player to AUDIO IN on your TV.
- 2 Using an S VIDEO cable, connect S VIDEO on your DVD player to S VIDEO on your TV.

Connecting a DVD player with component video output connectors

- This connection option offers the highest quality DVD picture.
- 1 Using AUDIO connectors, connect AUDIO R and L of the LINE OUT on your DVD player to AUDIO R and L on the VIDEO IN 4 panel at the rear of your TV.
 - 2 Using three VIDEO connectors, connect Y, Pb, and Pr on the COMPONENT VIDEO OUT on your DVD player to Y, Pb, and Pr on the VIDEO IN 4 panel at the rear of your TV.



- Note**
Some DVD player terminals may be labeled Y, Cr, and Cb, or Y, B-Y, and R-Y. If so, connect them by matching the colors.

8



Additional Connections

Connecting an audio system


- For an enhanced sound, connect your audio system to your TV.
- 1 Using AUDIO connectors, connect AUDIO OUT on your TV to one of the unused Line inputs (e.g., Tape 2, AUX1, etc.) on your stereo.
 - 2 Set your stereo to the chosen Line input and use the AUDIO 2 menu to set your audio output. (see page 20).




9



9



9



9

Connecting S-Link to a VCR

KV-27FV15, 32FV15, 36FV15 only

S-Link automatically powers on the TV and switches to the correct video input when a tape is inserted in the VCR.

- 1 Using A/V connectors, connect AUDIO and VIDEO OUT on your VCR to AUDIO and VIDEO IN on your TV.
- 2 Using an S-Link connector (mono mini plug), connect S-LINK on your VCR to S-LINK/CONTROL S-OUT in the same VIDEO IN column on your TV.




Connecting and Installing the TV (continued)

- Using Special Sony Features**
- Using the CONTROL S feature**

KV-27FV15, 32FV15, 36FV15 only

CONTROL S allows you to control your TV and other Sony equipment with one remote control. Using the supplied CONTROL S cable, connect CONTROL S IN on your Sony equipment, (e.g., VCR) to CONTROL S OUT on your TV.

Tip You can also program your remote control to operate other equipment, (see page 29).



— 11 —

Using Your New TV

Setting up the TV automatically

After you have finished connecting your TV, you will want to run AUTO PROGRAM to set up your channels. The AUTO PROGRAM feature does not apply for installations that use a cable box for all channel selection.

Tip

- Perform this function during the day, with the antenna and/or cable properly connected, to ensure that all available channels will be broadcasting and receivable.
- If your cable or antenna is connected to AUX, press ANT until AUX appears next to the channel number.

Tip To reset your TV to factory settings, turn the TV on. Then, while pressing the RESET button on your remote control, press the POWER button on your TV. The TV will turn itself off, then back on.

To reset your TV to factory settings, turn the TV on. Then, while pressing the RESET button on your remote control, press the POWER button on your TV. The TV will turn itself off, then back on.

To reset your TV to factory settings, turn the TV on. Then, while pressing the RESET button on your remote control, press the POWER button on your TV. The TV will turn itself off, then back on.

To reset your TV to factory settings, turn the TV on. Then, while pressing the RESET button on your remote control, press the POWER button on your TV. The TV will turn itself off, then back on.

To reset your TV to factory settings, turn the TV on. Then, while pressing the RESET button on your remote control, press the POWER button on your TV. The TV will turn itself off, then back on.


To reset your TV to factory settings, turn the TV on. Then, while pressing the RESET button on your remote control, press the POWER button on your TV. The TV will turn itself off, then back on.

To reset your TV to factory settings, turn the TV on. Then, while pressing the RESET button on your remote control, press the POWER button on your TV. The TV will turn itself off, then back on.

To reset your TV to factory settings, turn the TV on. Then, while pressing the RESET button on your remote control, press the POWER button on your TV. The TV will turn itself off, then back on.

Front panel menu control

The front panel menu controls allow access to the on-screen menus without the use of a remote control. Pressing the MENU button will bring up the on-screen menu. The arrow buttons (\uparrow , \downarrow) move the on-screen cursor in the menus and the (\times) button selects the menu item.



The supplied remote control has "arrow" buttons (\uparrow , \downarrow , \leftarrow , \rightarrow) which allow for movement of the on-screen (\blacktriangle) cursor.

Pressing on the outer buttons will cause the cursor to move in the corresponding direction. Pressing the center button (\times) will select the item.

- Remove the batteries to avoid damage from possible battery leakage whenever you anticipate that the remote control will not be used for an extended period.
- Handle the remote control with care. Avoid dropping it, getting it wet, or placing it in direct sunlight, near a heater, or where the humidity is high.
- Your remote control can be programmed to operate most video equipment, (see page 29).

Basic Set Up

Inserting batteries

Insert two size AA (R6) batteries (supplied) by matching the + and - on the batteries to the diagram inside the battery compartment.



Notes

- Remove the batteries to avoid damage from possible battery leakage whenever you anticipate that the remote control will not be used for an extended period.
- Handle the remote control with care. Avoid dropping it, getting it wet, or placing it in direct sunlight, near a heater, or where the humidity is high.
- Your remote control can be programmed to operate most video equipment, (see page 29).

— 12 —

13

Using Your New TV (continued)

Watching the TV
 The following chart explains more advanced buttons on your remote control.

Using the White Labeled Buttons for TV Operations

REFER TO THE ILLUSTRATION OF THE REMOTE CONTROL ON THE INSIDE FRONT COVER OF THIS MANUAL AS YOU REVIEW THIS CHART

Using the White Labeled Buttons for TV Operations	
DISPLAY	Press once to display current time (if set) and channel number. Press again to activate current CAPTION VISION setting. To cancel, press DISPLAY until DISPLAY OFF appears.
VIDEO	Press repeatedly to cycle through available video inputs: TV, VIDEO 1, VIDEO 2, VIDEO 3 and VIDEO 4
ANT	Press to change the VHF/UHF input to the AUX input.
AUX INPUT	
TV/VR	Press when you are finished using a VCR and you want to switch to the TV input. Your VCR power will remain on.
MTS/SP	Cycles through the Multi-channel TV Sound (MTS) options: STEREO, SAP (Second Audio Program), MONO. (see page 20).
SYSTEM OFF	Powers off all Sony equipment at once. <i>This feature may not work with older Sony equipment.</i>
T/SAT	Cycles through the available audio settings.

14

Using Your New TV (continued)

Using Picture-in-Picture - PIP

KV-27FV15, 32FV15, 36FV15 only
 These models are equipped with dual tuners.
 This means that PIP is "ready to use".

Indicates channel number currently receiving sound



- Notes**
- You must press TV (FUNCTION) before you can control PIP with the yellow labeled buttons.
 - The AUX input cannot be viewed in the window picture.

Use the Yellow Labeled Buttons for PIP Operations	
PIP	Displays the window picture. Press again to decrease the size. To cancel, press until the window picture turns off.
TV/VIDEO	Cycles through available video inputs: TV, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4
AUDIO	Alternates sound between the main picture and the window picture. A \downarrow will appear to indicate which picture is receiving sound.
TV/AVR	Changes the channel in the window picture.
POSITION	Moves the location of the window picture.
FREEZE	Press to freeze the window picture. Press again to restore the picture.
SWAP	Switches the position of the main picture with the window picture.

15

Using Your New TV

Learning menu selection

Use the MENU button to access a menu and use the arrow buttons (\uparrow or \downarrow) to alter settings. Use the following example, in which we activate the CABLE, to learn how to modify settings.

- 1 Press the MENU button.

The main menu appears.

2 Press \uparrow or \downarrow to highlight the desired menu (in this case SET UP \uparrow), and press \rightarrow to select it.

3 Press \uparrow or \downarrow to move to the desired option and press \rightarrow .

4 Press \uparrow or \downarrow to move to the desired feature and press \rightarrow . Options for your selection will be highlighted.

5 Press \uparrow or \downarrow to make your selection and press \rightarrow .

When you are finished making changes to the selected menu, choose \rightarrow MENU to return to the main menu.

Tip: Pressing MENU on the remote control will allow you to exit from the menus at any time.

CHANNEL SET UP	
SET UP	CHANNEL SET UP
CHANNEL	FAVORITE CHANNEL CHANNEL FIX CHANNEL SPREAD
VIDEO	VIDEO LEVEL VIDEO ADJUST VIDEO COLOR VIDEO TINT
AUDIO	AUDIO LEVEL AUDIO ADJUST AUDIO TILT AUDIO DIRECTION
DISPLAY	DISPLAY LEVEL DISPLAY ADJUST DISPLAY TILT DISPLAY DIRECTION
SYSTEM	SYSTEM LEVEL SYSTEM ADJUST SYSTEM TILT SYSTEM DIRECTION
2-MENU	
Move \uparrow	Select \rightarrow
Move \downarrow	Select \rightarrow
Move \leftarrow	Select \rightarrow
Move \rightarrow	Select \rightarrow
Exit	Exit


16

17

Using Your Menus (continued)

Quick start to the menus

The following is a guide to your menus.




To select a menu:
Display → Highlight ↓ Select →

Note
Menus shown are for KV-36FV15; your menus may not look exactly like those illustrated.

18

Using the VIDEO (III) menu

The VIDEO menu will allow you to make adjustments to your picture settings. It will also allow you to customize the picture MODE based on the type of program you are viewing.



To select the VIDEO (III) menu:
Display → Highlight ↓ Select →



The AUDIO menu offers enhanced audio options such as listening to second audio programming (SAP), or customizing the EFFECT of the sound on your TV.



The TIMER menu sets the clock on your TV and allows you to program your TV for scheduled viewing using the ON/OFF TIMER.



The SET UP menu provides several options for setting up your channels, labeling your TV/VIDEO inputs, and selecting the LANGUAGE of your menus.



The CHANNEL SET UP menu is a sub-menu which provides further options for setting up your TV.



The Basic Menu provides quick access to frequently used settings.



19

Using Your Menus (continued)

Using the AUDIO (I) menu

TREBLE Adjust left or right to decrease or increase higher pitched sounds.

BASS Adjust left or right to decrease or increase low pitched sounds.

BALANCE Adjust left or right to emphasize left and right speaker balance.

AUTO VOLUME Stabilizes volume (KV-27FV15, 32FV15, 36FV15 only)

ON: Select to stabilize the volume.
OFF: Select to turn AUTO VOLUME off.

EFFECT SIMULATED: Adds a surround-like effect to mono programs.
OFF: Normal stereo or mono reception.

MTS MONO: Select to reduce noise in areas with poor reception.
SAP: Select to listen to bilingual broadcast or other Second Audio Programs (SAP).
STEREO: Select when viewing a broadcast in stereo.

SPEAKER Custom selection of audio output source

ON: Select to listen to the sound from the TV speakers with or without a separate stereo system.
OFF: Select to turn off the TV speakers and listen to the TV's sound only through external audio system speakers.

AUDIO OUT VARIABLE: Adjust the volume through a connected stereo.
FIXED: Adjust the TV volume through a connected stereo.


MODE	Customized Picture viewing
SPORTS	Select for a finely detailed picture.
MOVIE	Select for a movie.
STANDARD	Select to receive a standard picture.
Press the PICTURE MODE button to access one of the above settings directly.	
PICTURE	Picture contrast
BRIGHTNESS	Picture adjustment
COLOR	Color saturation
HUE	Color tones
SHARPNESS	Picture detail
TRINITY	HIGH: Gives the white colors a blue tint. MEDIUM: Gives the white colors a neutral tint. LOW: Gives the white colors a red tint.
WHITE INTENSITY	ADJUSTMENT
COLOR CORRECT	ON: Emphasizes reds and blues. OFF: Emphasizes greens.

DAYLIGHT SAVING	YES: Select to compensate for Daylight Saving Time. NO: Select at the end of Daylight Saving Time.
CURRENT TIME SET	With the CURRENT TIME SET menu open: 1 Press OK until the current day is displayed. 2 Press ▲ or ▼ until the current hour and AM/PM is displayed. 3 Press OK to select. 4 Press ▲ or ▼ until the current minute is displayed, and press OK .
TIME SET	Necessary for the ON/OFF TIMER
ON/OFF TIMER	ON/OFF TIMER can be programmed before you can use the ON/OFF TIMER. With the ON/OFF TIMER menu open: 1 Choose the ON/OFF TIMER you would like to set and press OK . 2 Press ▲ or ▼ until the desired day or range of days is displayed. Press OK to select. 3 Indicate the time that you want the TV to turn on (hour, then minutes) by pressing ▲ or ▼ and then OK . 4 Set the time duration (maximum of 6 hours) by pressing ▲ or ▼ and then OK . 5 Press ▲ or ▼ until you reach the desired channel. Press OK to select. When you perform AUTO PROGRAM, all ON/OFF TIMER settings will be cleared.

Tip Set DAYLIGHT SAVING before setting the clock.

Using Your Menus (continued)

Using the SET UP menu



To select the SET UP menu:
Display → Highlight [] Select []

Note
The FAVORITE CHANNEL feature is not available for the AUX input.

- VIDEO LABEL Options:
VIDEO 1: VHS, 8mm, BETAMAX, LD, GAME, SAT, DVD, WEB.
Label connected equipment for easy recognition
- CAPTION VISION
Closed Captioning and channel information
- LANGUAGE
- TLT CORRECTION
- DEMO

22

Using the CHANNEL SET UP menu



To select the CHANNEL SET UP menu:
Display → Highlight [] Select []

Note
Your remote control can be programmed to operate your cable box. (see page 31)

- VIDEO LABEL window open:
1 Press ♦ or ♪ to choose the label and press [].
2 Press ♦ or ♪ to access the input you want to label and press [].
- VIDEO LABEL Options:
VIDEO 1/2/3: VHS, 8mm, BETAMAX, LD, GAME, SAT, DVD, WEB.
Label connected equipment for easy recognition
- CAPTION VISION
Closed Captioning and channel information
- LANGUAGE
- TLT CORRECTION
- DEMO

For detailed information on how to change your TV rating, see pages 27-28.

Notes

- The content ratings will increase depending on the level of the age-based rating. For example, a program with a TV-PG-V (Violence) rating may contain moderate violence, while a TV-14-V (Violence) rating may contain more intense violence.
- If you choose to block unrated TV programs, please be aware that the following programs may be blocked: emergency broadcasts, political programs, sports, news, public service announcements, religious programs and weather.

The CHANNEL SET UP menu is a submenu which provides further options for setting up your TV. (see page 23)

The PARENTAL CONTROL feature provides parents several options for programming the TV to block shows based on their rating. (see pages 25-28).

With the VIDEO LABEL window open:
1 Press ♦ or ♪ to access the input you want to label and press [].

With the CHANNEL CAPTION menu open:
1 Press [] and then ♦ or ♪ to access the desired channel, and press [] again.
2 Press [] or ♪ to display the first letter or number of the caption and press [] to select it.
3 Press [] to activate.

For detailed information on how to change your TV rating, see pages 27-28.

Using Your Menus (continued)

The CHANNEL SKIP/ADD menu provides further options for setting up your TV. (see page 23)

The PARENTAL CONTROL feature provides parents several options for programming the TV to block shows based on their rating. (see pages 25-28).

With the CHANNEL SKIP/ADD window open:
1 Use [] or [] to select the channel.
2 Press [] to SKIP or ADD only one option will be available).

With the CHANNEL CAPTION menu open:
1 Press [] and then ♦ or ♪ to access the desired channel, and press [] again.
2 Press [] or ♪ to display the first letter or number of the caption and press [] to select it.
3 Press [] to activate.

For detailed information on how to change your TV rating, see pages 27-28.

The Parental Guideline Rating System

This table provides a brief overview of the ratings systems available for the PARENTAL CONTROL feature.

- TV RATINGS
Block programs by their rating, content or both
- Age based options:
TV-Y: All children.
TV-Y7: Directed to older children.
TV-G: General Audience.
TV-PG: Parental Guidance suggested.
TV-14: Parents Strongly cautioned.
TV-MA: Mature Audience only.
- Content based options:
FV: Fantasy Violence.
D: suggestive Dialogue.
L: Strong Language.
S: Sexual situations.
V: Violence.

(U.S. models only)

- G: All children.
- TV-PG: Directed to older children.
- PG-13: General Audience.
- R: Parental Guidance suggested.
- NC-17: No one under 17 admitted.
- X: No one under 17 admitted.

(U.S. models only)

- VIEW ALL: Allows all unrated programming.
- BLOCK TV: Blocks all unrated TV programs.
- BLOCK MOVIE: Blocks all unrated movies.
- BLOCK ALL: Blocks all unrated programming.

Skip category
Movie [] Select [] Exit []

FAVORITE CHANNEL	Setting FAVORITE CHANNEL: 1 Press [] and then ♦ or ♪ to select AUTO or MANUAL. (Selecting AUTO will display the last five channels chosen with the remote control's C buttons.) 2 Press or ♪ to move the cursor to 1, 2, 3, 4 or 5 and press []. 3 Press ♦ or ♪ to access the desired channel and press []. To preview your favorite channels in the window picture, set PREVIEW to ON.
USING FAVORITE CHANNEL:	1 Exit all menus and press [], your FAVORITE CHANNEL options will appear. 2 Press ♦ or ♪ to access the channel you want to watch, and press []. For KV-27FV15, 32FV15, 36FV15 only.
USING FAVORITE CHANNEL:	1 Exit all menus and press [], your FAVORITE CHANNEL options will appear. 2 Press ♦ or ♪ to access the channel you want to watch, and press []. For KV-27FV15, 32FV15, 36FV15 only.
CABLE	ON: Select if you are using an antenna. OFF: Select if you are using a CABLE TV input. You will need to run AUTO PROGRAM after changing your CABLE settings.
CHANNEL FIX	2-6: Select when you want to control all channel selection through a cable box. Select the appropriate channel number (usually 3 or 4) and use the cable box's remote control for selection. AUX 2-6: Select when a cable box is alternate between. Press the AUX button to alternate between. VIDEO: Select from available video inputs when you have video equipment connected (e.g., satellite receiver) and you want your TV fixed to it.
AUTO PROGRAM	Instructs the TV to program all receivable channels.

23

FAVORITE CHANNEL	FAVORITE CHANNEL: 1 Press [] and then ♦ or ♪ to select AUTO or MANUAL. (Selecting AUTO will display the last five channels chosen with the remote control's C buttons.) 2 Press or ♪ to move the cursor to 1, 2, 3, 4 or 5 and press []. 3 Press ♦ or ♪ to access the desired channel and press []. To preview your favorite channels in the window picture, set PREVIEW to ON.
USING FAVORITE CHANNEL:	1 Exit all menus and press [], your FAVORITE CHANNEL options will appear. 2 Press ♦ or ♪ to access the channel you want to watch, and press []. For KV-27FV15, 32FV15, 36FV15 only.
USING FAVORITE CHANNEL:	1 Exit all menus and press [], your FAVORITE CHANNEL options will appear. 2 Press ♦ or ♪ to access the channel you want to watch, and press []. For KV-27FV15, 32FV15, 36FV15 only.
CABLE	ON: Select if you are receiving cable channels with a CATV cable. OFF: Select if you are using an antenna.
CHANNEL FIX	2-6: Select when you want to control all channel selection through a cable box. Select the appropriate channel number (usually 3 or 4) and use the cable box's remote control for selection. AUX 2-6: Select when a cable box is alternate between. Press the AUX button to alternate between. VIDEO: Select from available video inputs when you have video equipment connected (e.g., satellite receiver) and you want your TV fixed to it.
AUTO PROGRAM	Instructs the TV to program all receivable channels.

24

CHANNEL SKIP/ADD	With the CHANNEL SKIP/ADD window open: 1 Select the desired channel. 2 Press [] to SKIP or ADD only one option will be available).
CHANNEL CAPTION	With the CHANNEL CAPTION menu open: 1 Press [] and then ♦ or ♪ to access the desired channel, and press [] again. 2 Press [] or ♪ to display the first letter or number of the caption and press [] to select it. 3 Press [] to activate.
UNRATED	Block programs or movies that are broadcast without a rating VIEW ALL: Allows all unrated programming. BLOCK TV: Blocks all unrated TV programs. BLOCK MOVIE: Blocks all unrated movies. BLOCK ALL: Blocks all unrated programming.

25

Using Your Menus (continued)

Overview of the Ratings

ENGLISH RATINGS <i>For Canadian programs that are broadcast in English</i>	(Canadian models only) C: All children. C8+: Children 8 years and older. G: General programming. PG: Parental Guidance. 14+: Viewers 14 and older. 18+: Adult programming.
FRENCH RATINGS <i>For Canadian programs that are broadcast in French</i>	(Canadian models only) G: General programming. 8 ans+: Not recommended for young children 13 ans+: Not recommended for ages under 13. 16 ans+: Not recommended for ages under 16. 18 ans+: Programming restricted to adults.
U.S.A. RATINGS <i>For programs from the United States</i>	(Canadian models only) Please see TV RATINGS on page 25 for information on U.S.A. RATINGS.

See pages 25-26 for an overview of the rating systems available.

Using Your Menus (continued)

Setting the TV's RATING

This section provides information on how to set the TV's RATING and how to change your password.



Note

Entering your password to view a blocked program will temporarily turn PARENTAL LOCK to OFF. To reactivate your PARENTAL CONTROL settings, turn the TV off then back on; the TV will restore your rating settings.

- CHANGE PASSWORD**
- 1 Move the cursor to CHANGE PASSWORD and press **OK**.
- 2 Use the **0-9** buttons to create a new password, enter again to confirm.
- In the event that you forget your password, see page 33.

26

Using the PARENTAL CONTROL menu

This section shows you how to access the PARENTAL CONTROL menu. After you follow the example below, the next section shows you how to adjust your TV's rating.

- 1 Press MENU and select the SET UP menu.



- 2 Point the cursor to PARENTAL CONTROL and press **OK**.



You will be asked to enter a 4-digit password for any future access into the PARENTAL CONTROL menu.

- 3 Press **OK** and use the **0-9** buttons to enter your 4-digit password.



In order to change the RATING you will need to set PARENTAL LOCK to ON.

- 5 Point the cursor to PARENTAL LOCK and press **OK**. Press **OK** or **▼** to ON and press **OK**.



Now **OK** Set **OK** Exit **OK**

In order to change the RATING you will need to set PARENTAL LOCK to ON.

- 5 Point the cursor to PARENTAL LOCK and press **OK**. Press **OK** or **▼** to ON and press **OK**.



Now **OK** Set **OK** Exit **OK**

See pages 25-26 for an overview of the Parental Guideline ratings.

Tip

Keep this instruction manual in a safe place.

In the event that you forget your password, please see page 33.

27

Operating Video Equipment

Programming the remote

You can use the supplied remote control to operate Sony or non-Sony video equipment.

- 1 Press CODE SET.
- 2 Press VTR/DVD (FUNCTION).

3 Use the 0-9 buttons to key in the manufacturer's code number from the following chart.

- 4 Press ENTER.

VCR code numbers

Manufacturer

Code

Hitachi	306, 304, 305, 338
Instant Replay	309, 305, 304, 330, 314, 336, 337, 308
J.C. Penny	314, 336, 337, 345, 346, 347
Kenwood	327, 328, 335, 336, 337, 312, 311
LXI (Seas)	314, 330, 335, 337
Magnavox	332, 305, 309, 310
Marantz	308, 309, 310
Maxx	309, 310
Mitsubishi/MGMA	323, 324, 325, 326
NEC	325, 328, 329, 332
Olympic	312, 313, 310, 329
Panasonic	308, 309, 306, 307
Pentax	305, 304
Philco	308, 309
Phillips	308, 309, 310
Pioneer	308, 309
Quasar	304, 305, 308, 309, 311
RCA/PROSCAN	304, 305, 308, 309, 311
Realistic	309, 330, 328, 335, 334, 338
Sansui	312, 313, 310, 327
Samsung	304, 338, 309
Sanyo	312, 313, 321, 335, 323, 324, 335
Scott	341, 312, 309
Sharp	314, 336, 337
Shimtron	315
Signature 2000 (M. Ward)	338, 327
Sylvania	308, 309, 338, 310
Symphonic	329, 304, 309
Tashiro	322, 339, 340
Goldstar	314, 336, 337

To record Press **►** and **●** simultaneously.

To play Press **►**.

To stop Press **■**.

To fast forward Press **►►**.

To rewind the tape Press **◀◀**.

To pause Press **■**.

To resume normal playback, press again on press **►**.

To scan Press **◀** or **►** during playback.

To release normal playback, release the **◀** button.

Press **TV/VR** mode

28

29

Operating Video Equipment (continued)

Tips

- In some rare cases, you may not be able to operate your non-Sony video equipment with the supplied remote control. In this case, please use the equipment's own remote control.
 - When you remove the batteries, the code number may revert to the factory setting.
 - The code numbers for Sony VCRs are assigned at the factory as follows:
- | | | |
|--------------------|-----|---|
| VHS VCR | 301 | (preset code for the supplied remote control) |
| 8 mm VCR | 302 | |
| Beta, ED Beta VCRs | 303 | |
- If you will not be programming a satellite receiver or cable box into the SAT/CABLE function of your remote, you can use it to program other video equipment (e.g. DVD, MDP, or second VCR).

30

DVD (Digital Versatile Disc) code numbers

Manufacturer	Code	Manufacturer	Code
Sony	701	Panasonic	751
Panasonic	704, 710	Pioneer	753
Pioneer	702	RCA	755
Toshiba	754		

Buttons on the remote control		Buttons on a DVD player		Buttons on the remote control	
To turn on or off	Press VR/DVD (POWER).	To turn on or off	Press ■.	To turn on or off	Press VR/DVD (POWER).
To play	Press ▶.	To stop	Press ■.	To play	Press ▶.
To pause	Press ■.	To stop	Press ■.	To stop	Press ■.
To scan	Press ▶ or ▲ during playback.	To pause	Press ■.	To resume normal playback, press again or press ▶.	Press ■.
To search the chapter forward or backward	Press CH +/-.	To search the chapter forward or backward	Press CH +/-.	To resume normal playback, press ▶.	Press CH +/-.

Tip

If you will not be programming a satellite receiver or cable box into the SAT/CABLE function of your remote, you can use it to program other video equipment (e.g. DVD, MDP, or second VCR).

31

If the remote control doesn't work

Programming the remote control

- You can program the supplied remote control to operate a cable box or satellite receiver.
- Press CODE SET.
 - Press SAT/CABLE (FUNCTION).
 - Use the 0-9 buttons to key in the manufacturer's code number from the following chart.
 - Press ENTER.

For more details on operating the cable box or satellite receiver

Refer to the operating instructions that were supplied with the equipment.

Operating a Cable Box or Satellite Receiver

If more than one code number is listed, try entering them one by one until you come to the correct code for your equipment.

- If you enter a new code number, the code number you previously entered at that setting is erased.
- In some rare cases, you may not be able to operate your equipment with the supplied remote control. In this case, use the equipment's supplied remote control.
- Whenever you remove the batteries the code numbers may revert to the factory setting.

Cable box code numbers

Manufacturer	Code	Manufacturer	Code
Hamlin/Regal	222, 223, 224, 225, 226	Jerrold/G. I.	201, 202, 203, 204, 205, 206, 207, 208, 218
Panasonic	219, 220, 221	Pioneer	227, 228, 229
Toshiba	214, 215	Scientific Atlanta	209, 210, 211
	216, 217	Tocom	212, 213
		Zenith	

Satellite receiver code numbers

Manufacturer	Code	Manufacturer	Code
Sony	801 (preset code for remote control)	General Electric	802
Hughes	804	Panasonic	803
RCA/PROSCAN	802, 808	Toshiba	808, 807

Specifications

Supplied accessories

Remote control RM-Y168 (KV-32FV10, 36FS10 only), RM-Y171 (KV-27FV15, 32FV15, 36FV15 only)(1)	801 (preset code for remote control)
Batteries size AA (R6) (2)	

Troubleshooting

Consult the table below; it suggests solutions to specific problems.

Problem	What it could be	What you can do
You want to restore the TV's factory settings		<ul style="list-style-type: none"> First, turn the TV on. Then while pressing the RESET button on the remote control, press the POWER button. When the TV turns on again, all settings will be reset, and the initial setup screen will appear. Call your local Sony service center.
A red light keeps flashing on the TV for more than a few seconds	<ul style="list-style-type: none"> This is a normal function of your TV. Power cord may not be plugged in. Remote control batteries may not be inserted correctly. TV/VIDEO setting may be incorrect. Current program may exceed PARENTAL CONTROL settings. 	<ul style="list-style-type: none"> Check your power cord. Re-insert the batteries in your remote control. Press TV/VIDEO until you receive a channel. Check your PARENTAL CONTROL settings.
Poor or no picture (screen lit), good sound	<ul style="list-style-type: none"> Sound may be set to MUTING. Your TV may be set to SAP. SPEAKER may not be set correctly. Color settings may not be adjusted correctly. VIDEO menu settings may not be adjusted correctly. Antenna/cable connections may be faulty. VIDEO LATCH Inputs may be set to WEB. (This label darkens the screen for ideal WebTV viewing) 	<ul style="list-style-type: none"> Press MUTING. Readjust your VIDEO menu settings. (page 19). Check your SPEAKER settings. (page 20). Adjust the COLOR setting in the CHANNEL SET UP menu. (page 23). Ensure that you have selected the correct CABLE mode in the CHANNEL SET UP menu. (page 23). Press ANT on your remote control to change the input mode. (page 15).
Good picture, no sound	No color	<ul style="list-style-type: none"> Only snow and noise appear on the screen

If, after reading these operating instructions, you have additional questions related to the use of your Sony television, please call our Direct Response Center at 1-800-222-SONY (7669)(U.S. residents only) or (416) 499-SONY (7669)(Canadian residents only).

33

SECTION 3

SET-UP ADJUSTMENTS

The following adjustments should be made when a complete realignment is required or a new picture tube is installed.

These adjustments should be performed with rated power supply voltage unless otherwise noted.

The controls and switch should be set as follows unless otherwise noted:

PICTURE control normal

BRIGHTNESS control normal

Perform the adjustments in order as follows:

1. Beam Landing
2. Convergence
3. Focus
4. Screen (G2)/White Balance

Note: Test Equipment Required:

1. Color Bar Pattern Generator
2. Degausser
3. DC Power Supply
4. Digital Multimeter
5. Oscilloscope
6. CRT Analyzer


3-1. BEAM LANDING

Preparation:


- Input a white pattern signal.
- Face the picture tube in an East or West direction to reduce the influence of geomagnetism.

NOTE: Do not use the hand degausser because it magnetizes the CRT .


1. Input white pattern from pattern generator.
2. Loosen the deflection yoke mounting screw, and set the purity control to the center as shown below:




3. Input green pattern from pattern generator.
4. Move the deflection yoke backward, and adjust with the purity control so that green is in the center and red and blue are even on both sides.



5. Move the deflection yoke forward, and adjust so that the entire screen becomes green.



6. Switch over the raster signal to red and blue and confirm the condition.
7. When the position of the deflection yoke is determined, tighten it with the deflection yoke mounting screw.
8. When landing at the corner is not right, adjust by using the disk magnets.




3-2. CONVERGENCE

Preparation:


- Before starting, perform FOCUS, V. LIN and V. SIZE adjustments.
- Set BRIGHTNESS control to minimum.
- Input dot pattern.

(1) Vertical and Horizontal Static Convergence


- Adjust V. STAT magnet to converge red, green and blue dots in the center of the screen. (Vertical movement)



Tilt the V. STAT magnet and adjust static convergence to open or close the V. STAT magnet.




- When the V. STAT magnet is moved in the direction of arrow ① and ②, red, green, and blue dots move as shown below:



Operation of BMC (Hexapole) Magnet


The respective dot positions resulting from moving each magnet interact, so perform adjustment while tracking.

Use the VSTAT tabs to adjust the red, green, and blue dots so they line up at the center of the screen (move the dots in a horizontal direction.)



Y Separation Axis Correction Magnet Adjustment


- Input cross-hatch pattern, adjust PICTURE to minimum and BRIGHTNESS to normal.
- Adjust the deflection yoke upright so it touches the CRT.
- Adjust so that the Y separation axis correction magnet on the neck assembly is symmetrical from top to bottom (open state).



- Return the deflection yoke to its original position.

(2) Dynamic Convergence Adjustment


- Before starting, perform Horizontal and Vertical Static Convergence Adjustment.
- Slightly loosen deflection yoke screw.
 - Remove deflection yoke spacers.
 - Move the deflection yoke for best convergence as shown below:



- Tighten the deflection yoke screw.
- Install the deflection yoke spacers.


(3) Screen-corner Convergence

Affix a permalloy assembly corresponding to the misconverged areas:



(4) TLH Plate Adjustment

- Input crosshatch pattern.
- Adjust PICTURE QUALITY to standard, PICTURE and BRIGHTNESS to 50%, and OTHER to standard.
- Adjust the Horizontal Convergence of red and blue dots by tilting the TLH plate on the deflection yoke.





- Adjust XCV core to balance X axis.
- Adjust YCH VR to balance Y axis.
- Adjust vertical red and blue convergence with V.TILT (TLV VR.)

Perform adjustments while tracking items 1 and 2.


3-3. FOCUS

1. Input Monoscope signal.
2. Set user controls to normal.
3. Set Video mode to STANDARD.
4. Set the PICTURE to maximum.
5. Adjust FOCUS control for best picture at 325 MARK.



3-4. SCREEN (G2)

1. Input signal from the pattern generator.
2. Set the user controls to NORMAL.
3. Attach the G2-Jig to the C Board.
4. Adjust RCUT, GCUT, BCUT, and SBRT in service mode with an oscilloscope so that voltages on the red, green, and blue cathodes are 170 ± 2 V DC.
5. Observe the screen and adjust SCREEN (G2) VR to obtain the fairly visible background of dot signal.
6. Push the TEST +JUMP (+ Channel) to cut off the signal, then the screen is bright or dark. Brightness of raster must be increased when adjusting.
7. Adjust screen VR until the screen is just cut off, or scarcely lights up. A signal cannot be seen when the brightness of the raster is high.
8. Push the JUMP again to release the cut off.



3-5. WHITE BALANCE ADJUSTMENTS

NO.	Disp.	Item	All Models
24	RDRV	Red Drive	31
25	GDRV	Green Drive	31
26	BDRV	Blue Drive	31
27	RCUT	Red Cut-off	7
28	GCUT	Green Cut-off	7
29	BCUT	Blue Cut-off	7
38	SBRT	Sub Bright	7

1. Input an entire white signal.
2. Set to Service adjustment Mode.
3. Set DCOL to "0"
4. Set the PICTURE and BRIGHT to minimum.
5. Adjust with SBRT if necessary.
6. Select GCUT and BCUT with **[1]** and **[4]**.
7. Adjust with **[3]** and **[6]** for the best white balance.
8. Set the PICTURE and BRIGHT to maximum.
9. Select GDRV and BDRV with **[1]** and **[4]**.
10. Adjust with **[3]** and **[6]** for the best white balance.
11. Reset DCOL to "1".
12. Write into the memory by pressing **MUTING** then **ENTER** **.

SECTION 4

SAFETY RELATED ADJUSTMENTS


☒ R530, R531 CONFIRMATION METHOD (HOLD-DOWN CONFIRMATION) AND READJUSTMENTS

Always perform the following adjustments when replacing the following components marked with a **☒** mark on the schematic diagram:

A BOARD: IC355, IC501, D302, D519, D520, D521, C531, C532, Q301, R356, R359, R361, R387, R529, R530, R531, R532, R533, R550, T503

G BOARD (KV-27V15): IC643, R661

GA BOARD (KV-27V15 Excluded): IC6003, R6088



A BOARD - CONDUCTOR SIDE

Step 1 Preparation before Confirmation

Turn the POWER switch ON.

Input a white signal and set the PICTURE and BRIGHT controls to maximum.

Confirm that, when the set is operating normally, the voltage at check terminal TP85 is more than 21.0 V DC.


At AC input: 120.0 ± 2.0 VAC

Step 2

Input a white signal and verify that I ABL is within the specified range: 1730 ± 100 μ A,

$$+B = 135.0 \pm 1.5 \text{ VDC} .$$

At AC input: 120.0 ± 2.0 VAC



Step 3

Record the voltage between TP85 and ground.

Step 4

Using an external DC power supply, apply voltage between TP85 and ground.

Increase the voltage gradually and confirm that the holdown works (raster disappears) at lower than the voltage recorded in Step 3.

Lower than $26.95 \pm (-0.05)$ V DC.

At AC input: 120.0 ± 2.0 VAC

Step 5

Confirm that a voltage appears between TP85 and ground, of more than 21.0 V DC.

At AC input: 120.0 ± 2.0 VAC

B+ VOLTAGE CONFIRMATION AND ADJUSTMENT

Always perform the following adjustments when replacing the following components marked with **☒** on the schematic diagram:

G BOARD (KV-27FV15): IC643, R661

GA BOARD (KV-27FV15 Excluded): IC6003, R6088

- 1) Using Variac, apply AC input voltage: 130.0 ± 2.0 VAC
- 2) Input a monoscope signal.
- 3) Set the PICTURE control and the BRIGHT control to initial reset value.
- 4a) (KV-27FV15 Only) Confirm the voltage of G Board CN641 between pin ① to ground on "G" PWB is less than 136.5 ± 1.0 V DC.
- 4b) (KV-27FV15 Excluded) Confirm the voltage of GA Board CN6007, between pin ① to ground on "GA" PWB is less than 136.5 ± 1.0 V DC.
- 5a) (KV-27FV15 Only) If step 4a is not satisfied, replace R661 and repeat the above steps.
- 5b) (KV-27FV15 Excluded) If step 4b is not satisfied, replace R6088 and repeat the above steps.

SECTION 5 CIRCUIT ADJUSTMENTS

ELECTRICAL ADJUSTMENT BY REMOTE COMMANDER

Use Remote Commander (RM-Y171) to perform the following circuit adjustments:

NOTE : Test Equipment Required:


1. Pattern Generator
2. Frequency Counter
3. Digital Multimeter
4. Audio OSC

Method of Setting the Service Adjustment Mode

SERVICE MODE PROCEDURE


1. Standby mode. (Power off)
2. **[DISPLAY] → [5] → [VOL (+)] → [POWER]** on the Remote Commander.
(Press each button within a second.)

SERVICE ADJUSTMENT MODE IN




3. The CRT displays the item being adjusted.
4. Press **[2]** or **[5]** on the Remote Commander to select the device item.
5. Press **[1]** or **[4]** on the Remote Commander to select the item.
6. Press **[3]** or **[6]** on the Remote Commander to change the data.
7. If you want to recover the latest values press **[0]** then **[ENTER]** to read the memory.
8. Press **MUTING** then **[ENTER]** to write into memory**.

SERVICE ADJUSTMENT MODE MEMORY



9. Press **[8]** then **[ENTER]** on the Remote Commander to reset.



Carry out step 9) when adjusting IDs 0 to 4 and when replacing and adjusting IC102.


Factory original setting

10. Turn set off and on to exit.

Memory Write Confirmation Method

1. After adjustment, pull out the plug from the AC outlet, then replace the plug in the AC outlet again.
2. Turn the power switch ON and set to Service Mode.
3. Call the adjusted items again to confirm they were adjusted.

Adjust Buttons and Indicator



RM-Y171

WARNING: Do NOT turn off the power or AC immediately after pressing **MUTING then **ENTER**. Wait at least 10 seconds.

(4) Service Data

No.	Register Name	Description	Data Range	Adj/Fix	Initial Data	Average Data**	Comments
						All Models	
VP CXA2131S							
1	HPOS	Horizontal Position Adjust	0-63	Fix	7	7	
2	HSIZ	Horizontal Amp Adjust	0-63	Fix	10	10	
3	VBOW	VRT Line Bowing Adjust	0-15	Fix	6	6	
4	VANG	VRT Line Bow Slant Adjust	0-15	Fix	12	5	
5	TRAP	Horizontal Trapezoid Adjust	0-15	Fix	9	6	
6	PAMP	Horizontal Pin Distort Adjust	0-63	Fix	36	25	
7	UCPN	Upper Pin	0-63	Fix	25	25	
8	LCPN	Lower Pin	0-63	Fix	36	26	
9	VSIZ	Vertical Amplitude Adjust	0-63	Fix	0	0	
10	VPOS	Vertical Position Adjust	0-63	Fix	31	31	
11	VLIN	Vertical Linearity Adjust	0-15	Fix	7	7	
12	VSCO	S-Correction	0-15	Fix	7	7	
13	VZOM	16:9 CRT Z Mode On/Off	0,1	Fix	0	0	
14	EHT	VRT High Volt Correction	0-15	Fix	0	7	
15	ASP	Aspect Ratio Control	0-63	Fix	47	47	
16	SCRL	16:9 CRT Z Mode Tran Scroll	0-63	Fix	31	31	
17	HBSW	HBLK SW	0,1	Fix	1	1	
18	LBLK	Left Screen H Blk Control	0-15	Fix	15	15	
19	RBLK	Right Screen H Blk Control	0-15	Fix	0	0	
20	HDW	H Drive Pulse Width	0,1	Fix	0	1	
21	EWDC	EW/DC Adjust	0,1	Fix	0	0	
22	LVLN	Screen Bottom VRT Lin Adjust	0-15	Fix	0	0	
23	UVLN	Screen Top VRT Lin Adjust	0-15	Fix	0	0	
24	RDRV	R Output Drive Control	0-63	Adj	31	31	
25	GDRV	G Output Drive Control	0-63	Adj	31	31	
26	BDRV	B Output Drive Control	0-63	Adj	31	31	
27	RCUT	R Output Cutoff Control	0-15	Adj	7	7	
28	GCUT	G Output Cutoff Control	0-15	Adj	7	7	
29	BCUT	B Output Cutoff Control	0-15	Adj	7	7	
30	RDR4	Video 4 R Output Drive Control	0-63	Adj	31	31	
31	GDR4	Video 4 G Output Drive Control	0-63	Adj	31	31	
32	BDR4	Video 4 B Output Drive Control	0-63	Adj	31	31	
33	RCU4	Video 4 R Output Cutoff Control	0-15	Adj	7	7	
34	GCU4	Video 4 G Output Cutoff Control	0-15	Adj	7	7	
35	BCU4	Video 4 B Output Cutoff Control	0-15	Adj	7	7	
36	SHUE	Sub Hue	0-31	Adj	15	15	
37	SCOL	Sub Color	0-31	Adj	15	15	
38	SBRT	Sub Brightness	0-31	Fix	0	7	
39	RON	R Output On/Off	0,1	Fix	1	1	
40	GON	G Output On/Off	0,1	Fix	1	1	
41	BON	B Output On/Off	0,1	Fix	1	1	
42	AXPL	Axis Pal	0,1	Fix	0	0	
43	CBPF	Chroma BPF On/Off	0,1	Fix	1	1	
44	COFF	Color On/Off	0,1	Fix	0	0	
45	KOFF	Set Color Killer	0,1	Fix	0	0	
46	SSHP	Sub Sharpness	0-15	Fix	3	7	
47	SHPF	Sharpness Circuit F0	0,1	Fix	1	1	
48	PREL	Pre/Over-Shoot Switching	0,1	Fix	1	1	
49	Y-DC	DC Trans Ratio Switching	0,1	Fix	1	1	
50	ABLM	ABL Mode Switching	0,1	Fix	1	1	
51	YDEL	Y Delay Time Control	0-15	Fix	7	7	
52	NCOL	No Color ID	0,1	Fix	1	1	
53	FSC	FSC Out On/Off	0,1	Fix	1	1	
54	K-ID	Killer ID	0,1	Fix	0	1	
55	HOSC	H VCO Oscillation Frequency	0-15	Fix	7	7	
56	VSS	V Sync Slice Level	0,1	Fix	0	0	
57	HSS	H Sync Slice Level	0,1	Fix	0	0	
58	HMSK	H Mask	0,1	Fix	1	1	
59	VTMS	Select Signal VTIM Pin	0-3	Fix	0	0	

Service Data (cont.)

No.	Register Name	Description	Data Range	Adj/Fix	Initial Data	Average Data**	Comments
						All Models	
VP CXA2131S <i>continued</i>							
60	AFC	AFC Loop Gain	0-3	Fix	0	0	
61	FIFR	Field Frequency	0-3	Fix	3	3	
62	REFP	REFP	0,1	Fix	0	0	
63	VBSW	VBW	0-3	Fix	0	0	
64	BMOF	Blk Off	0,1	Fix	0	0	
65	AGN2	Aging 2	0,1	Fix	0	0	
AP B43868							
66	BBLP	BBE Low Pass	0-15	Fix	0	0	
67	BBHP	BBE High Pass	0-15	Fix	0	0	
68	SVOL	Sub Volume	0-15	Fix	0	0	
69	SBAL	Sub Balance	0-15	Fix	7	7	
70	SBAS	Sub Bass	0-15	Fix	7	7	
71	STRE	Sub Treble	0-15	Fix	7	7	
AP TDA7467							
72	SPCA	SRS/Space Attenuation	0-63	Fix	0	0	
73	CENA	SRS/Center Attenuation	0-63	Fix	0	0	
74	INPA	Input Attenuation	0-127	Fix	3	0	
3D UPD64081							
75	HHDS	HH Off	0-3	Fix	0	1	
76	COUT	Gain 1/BPF On	0-3	Fix	0	3	
77	YAPS	V Comp/Y Eaking On	0-3	Fix	0	3	
78	NSDS	Adaptive	0-3	Fix	1	0	
79	MSS	Adaptive	0-3	Fix	3	0	
80	DYC	Hi Impedance	0-3	Fix	1	2	
81	EXAD	Ext Ad Selected	0,1	Fix	0	1	
82	PECS	Standard	0-3	Fix	0	0	
83	EXCS	Use CSI Just In Case	0-3	Fix	1	1	
84	CPP	VTB = 1.25VPP	0-3	Fix	2	0	
85	HDP	H Phase +/- 0 μ sec	0-7	Fix	4	3	
86	CDL	Y/C Delay +/- 0 μ sec	0-7	Fix	1	4	
87	DYCO	Y Moving Coring	0-15	Fix	1	2	
88	DYGA	Y Moving Gain	0-15	Fix	12	10	
89	DCCO	C Moving Coring	0-15	Fix	2	2	
90	DCGA	C Moving Gain	0-15	Fix	12	9	
91	YNRK	Effect Small	0,1	Fix	0	1	
92	YNRI	Effect Small	0,1	Fix	0	0	
93	YNRL	Noise Limit	0-3	Fix	2	1	
94	CNRK	Effect Small	0,1	Fix	1	1	
95	CNRI	Effect Small	0,1	Fix	0	0	
96	CNRL	CNR Limit	0-3	Fix	1	1	
97	ID10	ID 1 Through	0,1	Fix	1	0	
98	ID1W	4:03	0,1	Fix	0	0	
99	ID1N	Normal	0,1	Fix	0	0	
100	CLK	Low Fix	0,1	Fix	1	1	
101	ST1S	Monitor Out	0-3	Fix	2	0	
102	ST0S	Monitor Out	0-3	Fix	1	1	
103	WSC	Coring	0-3	Fix	0	1	
104	VTRH	H Non Standard DET	0-3	Fix	1	1	
105	VTRR	H Non Standard DET	0-3	Fix	0	1	
106	LDSR	Frame	0-3	Fix	1	2	
107	PWRE	PWRE	0,1	Fix	0	0	
108	PDRE	PDRE	0-7	Fix	5	4	
109	PBRE	PBRE	0-15	Fix	6	8	
110	VAPG	V Apacon Gain	0-7	Fix	2	3	
111	VAPI	V Apacon	0-31	Fix	8	10	
112	TEST	Test	0,1	Fix	1	0	
113	YPFT	Y Peaking	0-3	Fix	2	3	

Service Data (cont.)

No.	Register Name	Description	Data Range	Adj/Fix	Initial Data	Average Data**	Comments
						All Models	
3D UPD64081 <i>continued</i>							
114	YPFG	Y Peaking Gain	0-15	Fix	10	10	
115	V1PS	Line Comb Dot H	0-3	Fix	0	2	
116	VEGS	Line Comb Dot V	0-3	Fix	3	2	
117	CC3N	C Width	0,1	Fix	1	0	
118	C0HS	C Delay On	0,1	Fix	0	0	
119	CLPH	Y-Ad Clamp Test	0,1	Fix	1	0	
120	SEL2	DC Sensitivity Small	0,1	Fix	0	0	
121	SEL1	DY Sensitivity Small	0,1	Fix	1	0	
122	YHCO	Coring Small	0-3	Fix	1	1	
123	YPCO	Coring On	0,1	Fix	0	0	
124	ED20	Standard	0,1	Fix	0	1	
125	OVST	Standard	0,1	Fix	0	0	
126	CSHD	Standard	0,1	Fix	1	0	
127	KCTT	Standard	0-3	Fix	0	0	
128	SHT1	Standard	0,1	Fix	1	0	
129	SHT0	Standard	0,1	Fix	0	0	
130	VCT	Standard	0,1	Fix	0	0	
131	OTT	Standard	0,1	Fix	1	0	
132	CGAT	Standard	0,1	Fix	0	0	
133	CGGT	Standard	0,1	Fix	0	0	
134	CGFT	Standard	0,1	Fix	0	0	
135	CGT	Standard	0,1	Fix	0	0	
136	HPLL	H PLL Fast	0,1	Fix	0	1	
137	BPLL	Burst PLL Fast	0,1	Fix	0	0	
138	FSCF	Burst Gain Large	0,1	Fix	0	0	
139	PLLF	PLL Loop Gain Large	0,1	Fix	0	1	
140	KILR	Killer Level	0-15	Fix	0	3	
141	HSSL	H Slice Level	0-15	Fix	9	12	
142	VSSL	V Slice Level	0-15	Fix	3	8	
143	BGPS	Start Burst Gate	0-15	Fix	12	4	
144	BGPW	Width of Burst Gate	0-15	Fix	8	10	
145	ADCL	ADC Clock	0-3	Fix	1	3	
146	ADPD	ADC Power Down On	0,1	Fix	0	1	
147	ADLT	Standard	0,1	Fix	0	0	
148	NRZO	Check On	0,1	Fix	A	0	
149	FSCO	Level Check On	0,1	Fix	0	0	
150	VTvh	Normal	0-3	Fix	2	0	
151	TST2	Standard	0,1	Fix	1	0	
152	HMEM	Use	0,1	Fix	1	1	
153	HINV	Polarity of Reset	0,1	Fix	1	1	
154	HTMG	Field Memory Address	0,1	Fix	0	0	
155	HCP	HH Carrier Phase	0-15	Fix	0	7	
156	TST3	Test	0,1	Fix	0	0	
157	HHMG	HH Moving Gain	0,1	Fix	1	1	
158	HHFG	HH	0-3	Fix	2	0	
159	HHTG	Max HH	0-15	Fix	7	5	
PI TA1226N							
160	SHPR	Picture Improvement Sharpness	0-127	Fix	89	59	
161	BLAD	Picture Improvement Black Area Detect	0-3	Fix	0	0	
162	SRTS	Picture Improvement SRT Start Pos	0-3	Fix	3	3	
163	YNR	Picture Improvement YNR	0,1	Fix	1	1	
164	GIRE	Picture Improvement Gamma Start Point	0-3	Fix	3	3	
165	DAC1	Picture Improvement DAC1	0,1	Fix	0	0	
166	DAC2	Picture Improvement DAC2	0,1	Fix	0	0	
167	GCUR	Picture Improvement Gamma Curve	0,1	Fix	0	0	
168	BLKC	Picture Improvement Black Compensation	0,1	Fix	1	1	
169	TEST	Picture Improvement Test	0-3	Fix	3	3	
170	RS	Picture Improvement RS	0-7	Fix	0	0	
171	RTC	Picture Improvement RTC	0-7	Fix	4	4	

Service Data (cont.)

No.	Register Name	Description	Data Range	Adj/Fix	Initial Data	Average Data**	Comments
						All Models	
DC CXA2060							
172	DCSF	Dynamic Convergence DC Shift	0-63	Fix	40	40	
173	UYBW	Dynamic Convergence Upper YBOW	0-63	Fix	31	31	
174	LYBW	Dynamic Convergence Lower YBOW	0-63	Fix	31	31	
175	HAMP	Dynamic Convergence H. Amp	0-63	Fix	15	15	
176	UCBW	Dynamic Convergence U. CBOW	0-63	Fix	21	21	
177	LCBW	Dynamic Convergence L. CBOW	0-63	Fix	14	14	
178	UMBH	Dynamic Convergence U. MBH	0-15	Fix	15	15	
179	LMBH	Dynamic Convergence L. MBH	0-15	Fix	15	15	
180	PWM	Dynamic Convergence PWM	0-63	Fix	63	63	
181	HTLT	Dynamic Convergence H. Tilt	0-63	Fix	1	1	
182	UTLT	Dynamic Convergence U. Tilt	0-63	Fix	1	1	
183	LTLT	Dynamic Convergence L. Tilt	0-63	Fix	1	1	
184	HDTY	Dynamic Convergence H. Duty	0-3	Fix	3	3	
185	TOFF	Dynamic Convergence Tilt Off	0,1	Fix	1	1	
186	DAC0	Dynamic Convergence DAC0	0-255	Fix	192	192	
187	DAC1	Dynamic Convergence DAC1	0-255	Fix	7	7	
SP SDA9288							
188	PYSD	P in P (Siemens) YS Delay	0-15	Fix	2	2	
189	PIPH	P in P (Siemens) H-Position	0-127	Fix	78	78	
190	PIPV	P in P (Siemens) V-Position	0-63	Fix	18	18	
191	PYDL	P in P (Siemens) Y-Delay	0-7	Fix	0	0	
192	PIFX	P in P Inset Fixed	0-3	Fix	2	2	
193	PPFX	P in P Parent Fixed	0-3	Fix	2	2	
194	PCLI	P in P CLISW	0,1	Fix	1	1	
195	PAMS	P in P AMSEC	0,1	Fix	0	0	
196	PHDL	P in P (Siemens) H-Pulse Delay (Inset)	0-15	Fix	15	15	
197	PMVD	P in P (Siemens) V-Pulse Delay (Main)	0-31	Fix	11	11	
198	PIVD	P in P (Siemens) V-Pulse Delay (Inset)	0-31	Fix	18	18	
199	PCON	P in P (Siemens) Contrast Level (Inset)	0-15	Fix	3	7	
200	FRMY	P in P (Siemens) Frame Y	0-15	Fix	10	10	
201	CHRI	P in P (Siemens) Chroma Input Polarity	0,1	Fix	0	0	
202	CHRO	P in P (Siemens) Chroma Output Polarity	0,1	Fix	0	0	
203	MAT0	P in P (Siemens) MAT0	0,1	Fix	1	1	
204	MAT1	P in P (Siemens) MAT1	0,1	Fix	1	1	
205	MAT2	P in P (Siemens) MAT2	0,1	Fix	0	0	
206	IPER	P in P (Siemens) Pedastel R-Y	0-15	Fix	0	0	
207	IPEB	P in P (Siemens) Pedastel B-Y	0-15	Fix	0	0	
208	PCPS	P in P (Siemens) CLP & HSIDEL	0,1	Fix	0	0	
209	PCPF	P in P (Siemens) CLP Cycles	0,1	Fix	0	0	
210	PSEL	P in P (Siemens) SELDOWN	0,1	Fix	1	1	
211	PPLL	P in P (Siemens) PLL Filter	0-3	Fix	0	0	
212	PVNR	P in P (Siemens) VSP Pulse Noise Red.	0,1	Fix	0	0	
IPPX IC CXA2019							
213	IDPX		0,1	Fix	0	0	
214	ICOL	Color	0-63	Fix	39	38	
215	ISHP	Sharpness	0-15	Fix	10	10	
216	ISCO	Sub Chroma Decoder Sub Cont	0-15	Fix	7	7	
217	ISCL	Sub Chroma Decoder Sub Color	0-15	Fix	8	12	
218	ISHU	Sub Chroma Decoder Sub Hue	0-15	Fix	7	7	
219	ITOT	Sub Chroma Decoder Tot On	0,1	Fix	0	0	
220	ITRP	Sub Chroma Decoder Trap On	0,1	Fix	1	1	
221	IAFC	AFC	0-3	Fix	1	1	
222	ITRA	Sub Chroma Decoder CTRAPADJ	0-15	Fix	7	7	
223	ICD2	Sub Chroma Decoder CD Mode2	0,1	Fix	1	1	
224	ISFO	SHP-F0	0,1	Fix	1	1	
225	IYDR	Sub Chroma Decoder Y Drive	0-31	Fix	24	24	
226	IVPE	Sub Chroma Decoder V Ped	0-15	Fix	0	0	
227	IUPE	Sub Chroma Decoder U Ped	0-15	Fix	0	0	
228	IRVP	Sub Chroma Decoder RV Ped	0-15	Fix	7	4	
229	IRUP	Sub Chroma Decoder RU Ped	0-15	Fix	7	4	

Service Data (cont.)

No.	Register Name	Description	Data Range	Adj/Fix	Initial Data	Average Data**	Comments
All Models							
IC CXA2019 continued							
230	IDCT	Sub Chroma Decoder DC Tran	0-7	Fix	4	4	
231	IRYD	Sub Chroma Decoder RY Drive	0-31	Fix	19	19	
232	IPRE	Sub Chroma Decoder Pre Over	0-3	Fix	1	1	
233	IRUD	Sub Chroma Decoder RU Drive	0-31	Fix	8	8	
234	IRVD	Sub Chroma Decoder RV Drive	0-31	Fix	8	8	
235	IDLY	Sub Chroma Decoder Delay	0-3	Fix	0	0	
236	ISCR	Sub Chroma Decoder SCP BGR	0-3	Fix	1	1	
237	ISCF	Sub Chroma Decoder SCP BGF	0-3	Fix	1	1	
DA CXA1315							
238	RTCO	D/A Converter N-S Correction	0-63	Fix	32	32	
239	2COL	Color	0-255	Fix	120	120	
240	2SHU	Sub Hue	0-31	Fix	15	15	
D1 CXD2085							
241	XJGL	XJGLK	0,1	Fix	0	0	
242	LNJ1	LNJ1	0,1	Fix	0	0	
CC CXP85856A							
243	CRIL	CCD CRI Pulse Compare Data Low	0-15	Fix	2	2	
244	CFLD	CCD Caption Fixed-Field Count	0-15	Fix	5	5	
245	CCDI	CCD No CCD Interrupt	0-7	Fix	3	3	
246	CRIP	CCD CRI & Parity Error	0-7	Fix	4	4	
247	CRIT	CCD CRI Time Constant	0-3	Fix	3	0	
248	CSB1	CCD Sync Slice Bias 1	0-3	Fix	3	3	
249	CSB2	CCD Sync Slice Bias 2	0-7	Fix	4	4	
250	CREP	CCD CRI Signal End Position	0-255	Fix	142	142	
251	CDSD	CCD Data Start Delay	0-31	Fix	8	8	
252	CCDS	CCD Caption Data Threshold	0-31	Fix	9	9	
253	CHMK	CCD P8-HMASK	0-63	Fix	42	42	
254	CHSY	CCD P8-HSYC	0-255	Fix	136	136	
OP CXP85856A							
255	DISP	OSD Position	0-63	Adj	4	1	
ID MAP							
256	ID 0	NVM ID 0	0-255	Fix by model	89	refer to NVM ID Chart	See ID map
257	ID 1	NVM ID 1	0-255	Fix by model	55		See ID map
258	ID 2	NVM ID 2	0-255	Fix by model	175		See ID map
259	ID 3	NVM ID 3	0-255	Fix by model	96		See ID map
260	ID 4	NVM ID 4	0-255	Fix by model	203		See ID map
261	ID 5	NVM ID 5	0-255	Fix by model	181		See ID map
262	ID 6	NVM ID 6	0-255	Fix by model	6		See ID map
263	ID 7	NVM ID 7	0-255	Fix by model	9		See ID map

(5) Feature ID Map


	ID 0	ID 1	ID 2	ID 3	ID 4	ID 5	ID 6	ID 7
KV-27FV15	89	55	175	96	203	181	6	0
KV-27FV15 CND	89	55	175	112	203	181	6	0
KV-29FV10	25	55	175	64	251	181	6	0
KV-29FV15, 15C	25	55	175	64	251	181	6	0
KV-29FV15K	137	55	175	64	219	181	6	0

SERVICE IDO 25


Note: Items 1-263 show adjustment order

SUB BRIGHT ADJUSTMENT (SBRT)


1. Set to Service adjustment Mode.
2. Input a gray scale pattern signal.
3. Set the PICTURE to minimum, and BRIGHT to normal.
4. Select SBRT with **[1]** and **[4]**.
5. Adjust SUB BRIGHT level with **[3]** and **[6]** so that the stripe second from the right is faintly visible.
6. Write into the memory by pressing **MUTING** then **ENTER**.




6. Write SHUE data 1 step down and SCOL data 2 steps up.
7. Write into the memory by pressing **MUTING** then **ENTER**.

**H. SIZE ADJUSTMENT (HSIZ)**

1. Input a monoscope signal.
2. Set to Service Adjustment Mode.
3. Select HSIZ with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best Horizontal size.
5. Write into the memory by pressing **MUTING** then **ENTER**.

H. SIZE**V. SIZE ADJUSTMENT (VSIZ)**

1. Input a monoscope signal.
2. Set to Service Adjustment mode.
3. Select VSIZ with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best vertical size.
5. Write into the memory by pressing **MUTING** then **ENTER**.

V. SIZE**V. POSITION ADJUSTMENT (VPOS)**

1. Input a monoscope signal.
2. Set to Service Adjustment Mode.
3. Select VPOS with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best vertical center.
5. Write into the memory by pressing **MUTING** then **ENTER**.

V. POSITION**SUB HUE, SUB COLOR ADJUSTMENT (SHUE, SCOL)**


1. Input a color bar signal.
2. Set to Service Adjustment Mode and set to
VIDEO mode = STANDARD
PICTURE = 100%
COLOR = 50%
HUE = 50%.
3. Connect an oscilloscope to CN351 Pin ③ of A Board.
4. Select SHUE and SCOL with **[1]** and **[4]**.
5. Adjust with **[3]** and **[6]** for the V1 = V4 (SCOL) and V2 = V3 (SHUE).

H. POSITION ADJUSTMENT (HPOS)

Perform this adjustment after H. FREQUENCY ADJ. (HFRE).

1. Input a monoscope signal.
2. Set the Service adjustment Mode.
3. Select HPOS with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best horizontal center.
5. Write into the memory by pressing **MUTING** then **ENTER**.

H. POSITION




V LINEARITY (VLIN), V CORRECTION (VSCO), PIN AMP (PAMP) AND TRAPEZIUM (TRAP) ADJUSTMENTS

1. Input a cross-hatch signal.
2. Set to Service adjustment Mode.
3. Select VLIN, VSCO, PAMP, and TRAP with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best picture.
5. Write the memory by Pressing **MUTING** then **ENTER**.

V LINEARITY(VLIN)




VS CORRECTION (VSCO)



PIN AMP (PAMP)




TRAPEZIUM (TRAP)



V ANGLE (VANG), V BOW (VBOW), UPPER PIN (UCPN) AND LOW PIN (LCPN) ADJUSTMENTS

1. Input a cross hatch signal.
2. Set to Service Adjustment Mode.
3. Select VVANG, VBOW, UCPN, and LCPN with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best picture.
5. Write the memory by Pressing **MUTING** then **ENTER**.

V ANGLE (VANG)




V BOW (VBOW)



UPPER PIN (UCPN)




LOW PIN (LCPN)



P&P SUB CONTRAST ADJUSTMENT (MSCO, ISCO)


1. Input a 75% color-bar signal.
2. Set: VIDEO mode = STANDARD
PICTURE = 100%
COLOR = minimum
GON = 0 (OFF), BON = 0(OFF),
TRINITONE = medium.
3. Set P&P mode.
4. Connect an oscilloscope to CN1103 pin **(4)** of A board and GND.
5. Set to Service Mode and select MSCO (main window) and ISCO (sub window) with **[1]** and **[4]**.
6. Adjust with **[3]** and **[6]** for the $1.75 \pm 0.05\text{Vp-p}$ of level.
7. Write into the memory by pressing **MUTING** then **ENTER**.



P&P SUB COLOR, SUB HUE ADJUSTMENT (MCOL, MSHU, ICOL, ISHU)

1. Input a 75% Color-bar signal.
2. Set: VIDEO mode = STANDARD
PICTURE = 100%
COLOR = 50%
HUE = 50%,
TRITONE = medium.
3. Set P&P mode.
4. Connect an oscilloscope to CN1103 pin **(5)** of A board and GND.
5. Set to Service Mode and select MCOL, MSHU (main window) and ICOL, ISHU (sub window) with **[1]** and **[4]**.


6. Adjust with [3] and [6].
7. After adjust write MSHU and ISHU data 1 step down.
8. Write into the memory by pressing [MUTING] then [ENTER].

**SUB HUE**


$V3-V2 = \pm 0.1V \rightarrow 1$ STEP DOWN
 $V3'-V2' = \pm 0.1V \rightarrow 1$ STEP DOWN

P&P ACQUISITION ADJUSTMENT (MAHP, MAVP)

1. Input a Monoscope signal.
2. Set PICTURE = 100%.
3. Set P&P mode and set CHANNEL INDEX mode.
4. Set to Service Mode and select MAHP and MAVP with [1] and [4].
5. Adjust with [3] and [6] for the best center (main window).
6. Write the memory by pressing [MUTING] then [ENTER].

**P&P WHITE BALANCE ADJUSTMENT (IUPE, IVPE)**


1. Input a 40 IRE white signal.
2. Set to VIDEO mode = STANDARD.
3. Set to P&P mode.
4. Set to Service Mode and select IUPE IVPE (sub window) with [1] and [4].
5. Adjust with [3] and [6] for white balance.
6. Write into the memory by pressing [MUTING] then [ENTER].

NEED TO ADJUST AFTER MAIN PICTURE (NOT P&P) W/B ADJUST

*9300 degrees K +8 MPCD

OSD POSITION ADJUSTMENT (DISP)

1. Input a color bar signal.
2. Set to Service adjustment Mode.
3. Select DISP with [1] and [4].
4. Adjust with [3] and [6] for the bar center.
5. Write into the memory by pressing [MUTING] then [ENTER].


**ROTATION COIL ADJUSTMENT**

1. Input a monoscope signal.
2. Push Menu button on the Remote (RM-Y171).
3. Select "Set Up" Mode.
4. Select "Tilt Correction". Confirm that number (0) color changes to red.
5. Push \uparrow (+) on the Remote (RM-Y171). Confirm that number increases up to +5 and picture rotates clockwise.
6. Push \downarrow (+) on the Remote (RM-Y171). Confirm that number decreases up to -5 and picture rotates counterclockwise.
7. Push \uparrow (+) on the Remote (RM-Y171). Return to 0.


SET-UP

- Channel Set-up
- Favorite Channel
- Video Label
- Language: English
- Tilt Correction : 0


CAUTION
Geom. adjustment condition must be 0.



6-1 BLOCK DIAGRAM (1/3)




SECTION 6 DIAGRAMS






6-2 BLOCK DIAGRAM (2/3)






KV-27FV15/29FV10/29FV15C/29FV15K

6-3 BLOCK DIAGRAM (3/3) (UY PIP BOARD - KV-29FV10 EXCLUDED)



6-4. CIRCUIT BOARDS LOCATION



6-5. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

- All capacitors are in μF unless otherwise noted. $\text{pF} : \mu\text{F} 50\text{VW}$ or less are not indicated except for electrolytics and tantalums.
- All electrolytics are in 50V unless otherwise specified.
- All resistors are in ohms. $K=1000, M=1000\text{k}$
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch : 5mm
Rating electrical power : $1/4\text{W}$

$1/4\text{W}$ in resistance, $1/10\text{W}$ and $1/8\text{W}$ in chip resistance.

- $\text{---} \square$: nonflammable resistor.
- $\text{---} \triangle$: fusible resistor.
- \triangle : internal component.
- \square : panel designation and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- The components identified by \blacksquare in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace with the value originally used.
- When replacing components identified by \blacksquare , make the necessary adjustments indicated. If results do not meet the specified values, change the component identified by \blacksquare and repeat the adjustment until the specified value is achieved. (Refer to R530 and R531 adjustment on Page 20.)
- When replacing the part in below table, be sure to perform the related adjustment.
- Readings are taken with a color-bar signal input.
- Readings are taken with a 10M digital multimeter.
- Voltages are DC with respect to ground unless otherwise noted.
- Voltage variations may be noted due to normal production tolerances.

- All voltages are in V.
- S : Measurement impossibility.
- $\text{---} \square$: B-line.
- $\text{---} \square$: B-line.
- (Actual measured value may be different).
- \rightarrow : signal path. (RF)
- Circle numbers are waveform references.

Reference information

RESISTOR	: RN METAL FILM
	: RC SOLID
	: FPRD NONFLAMMABLE CARBON
	: FUSE NONFLAMMABLE FUSIBLE
	: RW NONFLAMMABLE WIREWOUND
	: RS NONFLAMMABLE METAL OXIDE
	: RB NONFLAMMABLE CEMENT
	: \times ADJUSTMENT RESISTOR
COIL	: LF-8L MICRO INDUCTOR
CAPACITOR	: TA TANTALUM
	: PS STYROL
	: PP POLYPROPYLENE
	: PT MYLAR
	: MPS METALIZED POLYESTER
	: MPP METALIZED POLYPROPYLENE
	: ALB BIPOLAR
	: ALT HIGH TEMPERATURE
	: ALR HIGH RIPPLE

The symbol $\text{---} \square$ display is on the component side.
The components identified by shading and mark \triangle are critical for safety. Replace only with part number specified.
The symbol $\text{---} \square$ indicates a fast operating fuse.
Replace only with fuse of same rating as marked.

Les composants identifiés par un trame et une marque \triangle sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
Le symbole $\text{---} \square$ indique une fusible à action rapide. Doit être remplacée par une fusible de même valeur, comme maqué.


Part replaced(\blacksquare)	Adjustment(\blacksquare)
IC355, IC501, D302, D519, D520, D521, C531, C532, Q301, R356, R359, R361, R387, R529, R530, R531, R532, R533, R550, T503 A BOARD IC643, R661.....G BOARD (KV-27V15) IC6003, R6088.....GA BOARD (KV-27V15 Excluded)	R530, R531



KV-27FV15/29FV10/29FV15/29FV15C/29FV15K

A


[MICON, Y/C/J, TUNER, PIN-MOD, V-DEF, H-DEF]

**A BOARD
LOCATOR LIST**


DIODE	
D001	A-5
D002	D-2
D003	A-5
D004	C-2
D011	A-5
D012	C-1
D013	C-5
D014	D-3
D015	C-3
D017	D-3
D302	E-3
D303	D-4
D368	C-7
D384	F-6
D388	C-6
D501	H-2
D502	I-8
D503	I-8
D504	I-7
D505	I-6
D506	H-5
D507	H-2
D510	F-8
D511	F-9
D512	F-9
D513	F-9
D515	G-4
D516	H-2
D518	H-3
D519	G-9
D520	F-2
D521	F-2
D522	G-2
D530	G-8
D531	G-9
D534	G-8
D535	G-3
D536	G-3
D561	H-7
D1003	E-10
D1004	E-10
D1101	A-7
D1102	B-11
D1103	A-12
D1104	A-7
IC	
IC001	B-2
IC002	C-2
IC355	D-5
IC501	G-2
IC561	G-6
IC1001	D-8
TRANSISTOR	
Q001	A-5
Q002	C-4
Q003	H-1
Q004	H-1
Q005	B-5
Q006	H-1
Q007	I-1
Q010	D-3
Q011	D-3
Q012	D-3
Q013	D-3
Q014	D-3
Q015	D-3
Q016	D-2
Q017	A-5
Q103	B-8
Q104	B-8
Q301	E-3
Q302	E-5
Q303	E-7
Q304	E-5
Q305	E-5
Q306	E-5
Q307	C-6
Q310	E-4
Q311	E-4
Q315	D-6
Q501	I-2
Q502	J-9
Q503	G-3
Q504	G-3
Q507	F-9
Q511	H-2
Q512	F-3
Q561	G-6
Q562	F-5
Q1102	A-12
Q1103	A-10



A BOARD SCHEMATIC DIAGRAM



A BOARD WAVEFORMS




A BOARD IC VOLTAGE LIST


IC	Pin	Volt	IC	Pin	Volt	
IC001	41	0	7	5.3		
	1	0	8	5.4	1	-0.1
	2	5.0	44	2.7	10	GND
	3	0	45	2.8	11	0
	4	4.7	46	2.4	12	7.0
	5	NC	47	4.9	13	3.5
	6	4.9	48	GND	14	3.5
	7	0.1	49	GND	15	6.1
	8	0	50	5	16	7.6
	9	5.0	51	4.8	17	12.9
	10	NC	52	0	18	5.5
	11	NC	53	4.5	19	2.8
	12	5	54	4.5	20	2.6
	13	4	55	4.5	21	1.8
	14	4.9	56	4.5	22	1.4
	15	0	57	5.4	23	1.2
	16	5.7	58	0	24	1.2
	17	2.4	59	3.6	25	NC
	18	0	60	3.7	26	NC
	19	5.0	61	0	27	NC
	20	2.3	62	4.7	28	0
	21	0	63	0	29	2.0
	22	0	64	0	30	4.7
	23	0	65	4.7	31	0
	24	0	66	4	32	4
	25	GND	67	9.3	33	6
	26	2	68	4.6	34	7
	27	0	69	4.5	35	0
	28	0.5	70	4.5	36	0.3
	29	5	71	4.5	37	0
	30	0	72	4.6	38	5.6
	31	0	73	4.6	39	5.6
	32	0	74	4.6	40	13
	33	0	75	4.6		
	34	NC	76	4.1		
	35	NC	77	4.2		
	36	0	78	5.3		
	37	0	79	4.4		
	38	0	80	5.2		
	39	0	81	4.7		
	40	0	82	4.8		

All voltages are in V

A BOARD: IC 355 CXA2131S



A BOARD: IC 561 STV9379




A BOARD TRANSISTOR VOLTAGE LIST

B	C	E
Q0001	5.0	0.4
Q0002	-0.4	4.3
Q0003	5.2	GND
Q0004	0	5.0
Q0005	0	5.0
Q0006	0	5.0
Q0007	5.0	5.0
Q010	0	0.5
Q011	0	9.5
Q012	0	9.5
Q013	0	0
Q014	0	0
Q015	0	GND
Q016	5.7	9.5
Q017	4.3	5.0
Q103	4.2	4.8
Q104	5.0	0
Q302	-0.5	3.5
Q303	4.2	8.2
Q304	1.4	GND
Q305	1.2	GND
Q306	1.2	GND
Q310	1.6	2.3
Q311	3.8	1.9
Q501	-0.8	107.7
Q502	0	134.0
Q503	0	8.1
Q504	0	GND
Q507	0.3	45.3
Q511	-12.9	-9.9
Q512	-13.0	14.6
Q561	0	6.1
Q562	-0.2	GND
Q563	5.8	9.1
Q1103	0	5.2

A BOARD (*) MARK LIST

REF. NO.	LOCATION	KV29FV15	KV29FV15C	KV29FV10	KV29FV15K
C313	D-17	#	#	0.01	#
C314	D-18	0.1	0.1	#	0.1
C315	D-17	#	#	0.01	#
C316	D-18	0.1	0.1	#	0.1
C317	D-17	#	#	0.01	#
C318	D-18	0.1	0.1	#	0.1
CN272	N-3	15P	#	15P	
CN1102	N-4	3P	#	3P	
D368	J-2	ISS133T-77	ISS133T-77		ISS133T-77
JR055	D-19	1-216-295-91	1-216-295-91	#	1-216-295-91
JR056	D-19	1-216-295-91	1-216-295-91	#	1-216-295-91
JR057	D-19	1-216-295-91	1-216-295-91	#	1-216-295-91
L103	N-4	JW	#	JW	
L104	N-4	JW	#	JW	
Q103	M-5	2SA1162-G	2SA1162-G	#	2SA1162-G
Q104	M-4	2SD601A-Q	2SD601A-Q	#	2SD601A-Q
R106	L-5	22K	22K	#	22K
R107	M-5	22K	22K	#	22K
R108	L-4	22K	22K	#	22K
R109	M-4	22K	22K	#	22K
R386	J-2	1K	1K	#	1K
TU102	D-3	8-598-431-00	8-598-431-00	8-598-431-00	8-598-475-00



G BOARD IC VOLTAGE LIST

IC6000	pin	volt	IC643	pin	volt
	REF	2.5		1	134.2
	ANODE	GND		2	NC
	CATHODE	5.0		3	2.4
IC601	4	8.8		4	8.8
	5	GND		5	GND

All voltages are in V

G BOARD TRANSISTOR VOLTAGE LIST


B	C	E
Q622	0.5	1.7
Q623	0.7	0
Q624	12.8	0
Q644	0	12.0
Q645	11.8	GND
Q646	6.3	7.0
Q647	0	11.7
Q648	0.7	0.1
Q649	12.0	0
Q650	0	2.3
Q651	135.2	0
Q652	3.6	0
Q653	0	3.6
		GND

All voltages are in V

C BOARD TRANSISTOR VOLTAGE LIST

B	C	E
Q1790	4.7	



All voltages are in V




C BOARD IC VOLTAGE LIST

IC1701	pin	volt
	1	1.8
	2	1.0
	3	2.4
	4	gnd
	5	4.7
	6	205.8
	7	139.6
	8	149.6
	9	152.2

All voltages are in V

**G BOARD SCHEMATIC DIAGRAM****G [POWER SUPPLY]**


G





KV-27FV15/29FV10/29FV15/29FV15C/29FV15K

GA BOARD SCHEMATIC DIAGRAM




GA BOARD IC VOLTAGE LIST

IC6000	IC6002	IC6003
REF 7.00V	REF 3.07V	REF 134.0
ANODE GND	2 189.7	2 NC
CATHODE 5.0	3 3.9	3 2.4
IC6001	4 NC	4 10.1
pin volt	5 4.5	5 GND
1 17.9	6 2.1	
2 17.9	8 3.8	
3 3.2	9 GND	IN 13.4
4 3.2	10 GND	OUT 11.9
5 3.2	11 0	GND GND
6 3.2	12 0	IN 11.4
7 4.3	13 0	OUT 9.5
8 3.2	14 0.8	GND 0.4
9 4.9	15 10.8	
10 3.4	16 4.7	
11 4.8	17 0	pin volt
12 GND	18 17.2	IN 7.2
13 17.9	19 163.4	OUT 5.0
14 17.9		GND GND

GA BOARD LOCATOR LIST

DIODE	J-1
D6001	J-4
D6002	C-4
D6003	C-4
D6004	B-4
D6005	B-4
D6006	C-5
D6007	C-5
D6008	E-4
D6009	E-4
D6010	C-3
D6011	J-6
D6012	I-4
D6013	D-3
D6014	B-3
D6015	C-2
D6016	F-1
D6017	H-5
D6018	H-2
D6019	J-5
D6020	G-2
D6021	E-5
D6022	F-3
D6023	G-3
D6024	I-5
D6025	G-4
D6026	D-4
D6027	E-4
D6028	H-2
D6029	E-3
D6030	H-3
D6031	I-6
D6032	F-3
D6033	H-6
D6034	J-5
D6035	H-2
D6036	H-2
D6037	I-5
D6038	E-4
D6039	D-3
D6040	C-4

GA [POWER SUPPLY]




GA BOARD TRANSISTOR VOLTAGE LIST

B	C	E
Q6000	1.0	9 GND
Q6001	0.7	0.1
Q6002	13.2	0 13.2
Q6003	16.9	17.6 17.8
Q6004	0.7	0 GND
Q6005	0.6	0 GND
Q6007	0.3	1.5 0
Q6008	3.6	0 3.6
Q6009	134.3	0 134.7
Q6010	17.1	17.7 17.8
Q6011	17.1	0 17.9
Q6012	17.1	0 17.9

GA BOARD TRANSISTOR VOLTAGE LIST


D	G	S
Q6006	150.0	1.5 GND

HB BOARD SCHEMATIC DIAGRAM




HB [IR DETECTOR]


HB [IR DETECTOR]



HX BOARD SCHEMATIC DIAGRAM



HX [KEY]



Schematic diagrams

← C | G boards
GA | HA | HB | HX boards →

— 53 —

— 54 —

4/15/99 2:17 PM


— 55 —

— 56 —



KV-27FV15/29FV10/29FV15/29FV15C/29FV15K

UY BOARD SCHEMATIC DIAGRAM (1/2)



— 57 —

— 58 —

— 59 —

4/15/99, 1:27 PM

UY (MAIN) BOARD IC VOLTAGE LIST

IC261	pin	volt	IC3504	pin	volt
	29	0	28	1	1.6
	31	4.6	29	0	GND
D002	2	4.6	32	4.5	62
D010	3	4.6	33	GND	63
D011	4	4.6	34	NC	4.6
D012	5	4.6	35	4.4	4.6
D013	6	4.6	36	NC	volt
D014	7	4.6	37	NC	1
D015	8	4.6	38	NC	2
D016	9	NC	39	9.1	3
D017	10	4.6	40	NC	4
D018	11	NC	41	NC	5
D019	12	0	42	4.6	6
D020	13	4.6	43	NC	7
D021	14	4.6	44	NC	8
D022	15	NC	45	NC	9
D023	16	NC	46	GND	10
D024	17	4.6	47	NC	11
D025	18	0	48	GND	12
D026	19	4.6	49	4.6	13
D027	20	4.6	50	4.6	14
D028	21	4.6	51	4.6	15
D029	22	4.6	52	4.7	16
D030	23	4.6	53	4.6	17
D031	24	4.4	54	4.7	18
D032	25	NC	55	4.5	19
D033	26	NC	56	4.6	20
D034	27	4.6	57	GND	21
D035	28	4.6	58	4.6	22


All voltages are in V

UY (MAIN) BOARD TRANSISTOR VOLTAGE LIST

Q212	B	C	E
Q231	4.6	9.1	3.9
Q233	-0.1	0	GND
Q234	-0.1	0	GND
Q235	-0.1	0	GND
Q236	-0.1	0	GND
Q237	4.6	GND	0.3
Q238	4.7	GND	5.3
Q239	4.7	GND	5.3
Q246	0.3	0.2	GND
Q262	4.6	GND	5.2
Q263	4.6	GND	5.2
Q264	4.4	GND	5.0
Q265	4.5	9.1	3.8
Q266	4.6	GND	5.2
Q267	0.2	GND	0.9
Q1051	9.1	-1.4	9.0
Q1202	8.6	0	9.1
Q1203	0	4.4	GND
Q1204	8.6	0	9.1
Q1205	4.6	9.1	4.0
Q1206	4.6	9.1	4.0
Q2003	1.1	GND	1.8
Q2005	4.6	GND	1.8
Q2006	4.5	9.1	3.8
Q2007	2.3	4.4	1.7
Q2008	2.3	4.6	1.6
Q2009	4.4	9.1	3.7
Q2010	4.6	9.1	3.9
Q2011	4.6	9.1	4.4
Q2018	4.1	GND	4.8
Q2019	5.2	9.1	4.5

All voltages are in V

UY (MAIN) BOARD WAVEFORMS



UY MAIN BOARD (*) MARK LIST

REF. NO.	LOCATION	KV27FV15	KV29FV15	KV29FV10	KV29FV15K
CN261	A-10	7P	7P	#	7P
D002	L-2	MTZJ-T-9110	MTZJ-T-9110	#	MTZJ-T-9110
D010	J-2	MTZJ-T-9110	MTZJ-T-9110	#	MTZJ-T-9110
D011	J-2	MTZJ-T-9110	MTZJ-T-9110	#	MTZJ-T-9110
J902	L-2	3P	3P	#	3P
J903	J-2	3P	3P	#	3P
J904	J-2	3P	3P	#	3P
R902	L-2	100	100	#	100
R921	J-2	100	100	#	100
R922	J-2	100	100	#	100

