

## DISC REMOVAL METHOD AT NO POWER SUPPLY

1. Remove the Back Cabinet and Angle Deck. **(Refer to item 1 of the DISASSEMBLY INSTRUCTIONS.)**
2. Slide the Belt Loading toward the arrow direction by hand to release the lock. **(Refer to Fig. 1)**
3. Take out the Disc from the DVD Deck. Be careful not to scratch on the Disc.

DVD Deck




Fig. 1