

PARENTAL CONTROL - RATING LEVEL

4 DIGIT PASSWORD CANCELLATION

If the stored 4 digit password in the Rating Level menu needs to be cancelled, please follow the steps below.

1. Turn Unit ON.
2. Set the DVD to the Stop Mode.
3. Check that "No disc" is displayed on the screen.
4. Press and hold the "STOP" button on the front panel.
5. Simultaneously press and hold the "7" key on the remote control unit.
6. Hold both keys for more than 2 seconds.
7. The On Screen Display message "PASSWORD CLEAR" will appear.
8. The 4 digit password has now been cleared.