


2. Overview of the Dryer



3. Overview of the control panel

(DV5008J)



1. SIGNAL button

Initial mode is set to OFF at the factory, and no completion buzzer makes sound. Push the SIGNAL button to turn the SIGNAL lamp ON and make the completion buzzer sound.

2. TEMPERATURE button

Initial mode is set to OFF at the factory. Push TEMPERATURE button to select LOW temperature and turn lamp ON.

3. TIME button

TIME button displays 90(1:30) minutes at its initial mode. You can decrease each 10 minutes by pushing the button each one time.
(1:30 → 1:20 → 1:10 → 1:00 → 30 → 20 → 1:30)

4. DELAY START button

DELAY START button is to be selected in order of 1 hour → 2 hours → 3 hours → ...24 hours → Cancel.

5. Wrinkle-Free button

Push Wrinkle-Free button to run COOL DOWN 10 minutes after adjusting temperature for 10 minutes.

6. Selection of cycle

Turn Dial to indicate cycles in the following order.

Cotton+Cupboard#→Cotton+Light #→ Cotton+Iron#→Cotton+Rotary Iron#→ Airing #→Synthetic+Extra#→Synthetic+Very#→Synthetic+Cupboard#→Synthetic+Light#→ Synthetic+Iron#→Synthetic+Rotary Iron #→ Airing #→ Cotton+Extra #→ Cotton+Very #→ Cotton+Cupboard

7. FILTER lamp

Turn the system ON to let FILTER lamp flicker 3 times. When a drying cycle is finished, FILTER lamp turns ON to display cleaning instruction of filter.

8. CHILD LOCK lamp

When the system turns ON, push Wrinkle-Free button and DELAY START button in order to turn CHILD LOCK lamp ON. From this time, all of buttons do not operate. To cancel the mode, push DELAY START button and Winkle-Free button in reverse order.

9. START/PAUSE button

Press the button to start and pause the system.

10. POWER button

Press the button one time to turn the system ON, press it once more to turn the system OFF. When the system turns ON for longer than 10 minutes without pressing any button, it automatically turns OFF.

4. Time Chart

COURSE		Dryer Temperature Control			TOTAL	Add Time ANTI CREASE	Minimum (Dry)Time	Target Temperature	Dryerness
		Sensing	Dry	Cool Down					
COTTON (HIGH)	EXTRA	3'	1:42'	5'	1:50'	45'	40'	53 ± 3	101%
	VERY	3'	1:37'	5'	1:45'	45'	40'	51 ± 3	100%
	CUPBOARD	3'	1:32'	5'	1:40'	45'	40'	49 ± 3	97%
	LIGHT	3'	1:27'	5'	1:35'	45'	40'	47 ± 3	95%
	IRON	3'	1:22'	5'	1:30'	45'	25'	43 ± 3	87%
	ROTARY IRON	3'	1:17'	5'	1:25'	45'	25'	41 ± 3	84%
SYNTHETIC (LOW)	EXTRA	3'	1:07'	10'	1:20'	45'	30'	48 ± 3	101%
	VERY	3'	1:02'	10'	1:15'	45'	30'	46 ± 3	100%
	Cupboard	3'	57'	10'	1:10'	45'	30'	45 ± 3	97%
	LIGHT	3'	52'	10'	1:05'	45'	30'	44 ± 3	95%
	IRON	3'	47'	10'	1:00'	45'	15'	41 ± 3	87%
	ROTARY IRON	3'	37'	10'	50'	45'	15'	39 ± 3	84%
Wrinkle-Free		-	10'	10'	20'	-		35 ± 3	
Airing		-		50'	50'	-		-	
Time Dry		1:20'~10"		10"	130'~20				

