


SAMSUNG

CLOTHES DRYER

DV5008JGW3/YGG

SERVICE *Manual*

CLOTHES DRYER



CONTENTS



Caution for safety during servicing

1. SPECIFICATIONS
2. OVERVIEW OF THE DRYER
3. OVERVIEW OF THE CONTROL PANEL
4. TIME CHART
5. GENERAL ERROR FUNCTION
6. TROUBLE DIAGNOSIS
7. TEST MODE
8. DESIGNATION OF MAIN COMPONENTS
9. PCB SCHEMATIC DIAGRAM
PCB CIRCUIT DIAGRAM
10. ASSEMBLE AND DISASSEMBLE
11. TOOLS FOR DISASSEMBLY AND ASSEMBLY
12. EXPLODED VIEW AND PARTS LIST



Caution for safety during servicing

1. Do not allow the customer to repair the product.

The person may be injured or the product life may be shortened..

2. Execute A/S after unplugging the power supply unit.

Be careful of the electric shocks.

3. Do not plug several plugs in the same outlet.

It may cause a fire due to overheat.

4. Check for damage, pressing or burning of the power plug or outlet.

Replace it promptly if it has a problem.(It may cause the electric shocks or fire)

5. Do not clean the main body with water.

It may cause electric shocks and fire and shorten the product life)

6. The wiring of the harness shall be free from moisture and tightened during serving.

It shall not be deviated by certain impact.

7. Remove any dust or filth on the housing section,wiring section,connection section during servicing.

Protect from possible cause of fire such as the tracking,shortage etc.

8. Check for any marks of moisture on the electrical parts, harness section etc.

Replace the parts or remove the moisture..

9. Check the assembly status of the parts after servicing.

Maintain the status before servicing..

10. Pull out the power cord by holding the plug.

Be careful of electric shocks and when the cord is damaged.

11. Unplug the power plug from the outlet when the dryer is not used.

Be careful of electric shocks and fire due to the strike of lightning.

12. Do not use or store sprays or flammable materials(including gasoline,alcohol etc.) around the dryer.

Be careful of explosions or fire due to electric sparks.

13. Do not put bowls of water or wet laundry on the dryer.

If water has penetrated into the dryer, this may cause electric shocks or fire.

14. Do not install the dryer where it will be exposed to bad weather.

It may cause electric shocks and fire and shorten the product life.

15. Do not push the control buttons with an awl,pin, or sharp materials.

It may cause electric shocks and damage.

16. Check the wash machine is leveled horizontally and installed properly on the floor.

The vibration may shorten the product life..