



## 5 Troubleshooting

- Notes:**
- Before troubleshooting, setup the PC's display as below.
    - Resolution: 1024 x 768
    - H-frequency: 48 kHz
    - V-frequency: 60 Hz
  - If no picture appears, make sure the power cord is correctly connected.
  - Check the following circuits.
    - No raster appears: SMPS PCB, Main PCB
    - 12V develop but no screen: Main PCB
    - 12V does not develop: SMPS PCB
  - If you push and hold the "EXIT" button for more than 5 seconds, the monitor automatically returns to the factory preset.


### 5-1 No Power



\* 0V means power on state.

**5-2 No Video**

# WAVEFORMS



**Memo**