



<b>ID</b>	<b>Ref. de producto</b>	<b>Sustituido</b>	<b>descripción</b>
8401	00561599		Instrucciones de uso
8401	00549094		Instrucciones de uso
0101	00607512		Cable
0102	00642417		Base cuerpo
0103	00607481		Abrazadera
0104	00607541		Tornillo
0105	00607499		Junta
0106	00612721		Conjunto de cables
0107	00612722		Modulo electrónico
0108	00615816		Caja-pared trasera
0109	00611050		Elemento calefactor
0110	00612745		Tapon
0111	00607540		Resorte
0114	00607482		Junta
0115	00612723	00607526	Bomba
0116	00607527		Amortiguador
0117	00607537	00647385	Tubo
0120	00607475		Regulador
0121	00607523		Válvula
0122	00607469		Soporte
0123	00607501		Interruptor
0124	00649023		Tapa frontal
0125	00607488	00616467	Botón
0126	00607479		Resorte
0127	00607478		Resorte
0131	00607472	11002578	Depósito
0132	00642421		Depósito

0133	00642341	00650793	Junta
0134	00607535	00652278	Tapa
0136	00642418		Cuerpo superior
0139	00676331		Tapa
0140	00676330	00753772	Tapa
0142	00607480		Abrazadera
0150	00607524		Electroválvula
0180	00611064		Conjunto de cables
0181	00611063		Conjunto de cables
0182	00611062		Lentilla
0152	00611099	00618272	Tapon
0151	00611100	00618272	Tapon
8800	00402707		Centro de planchado