

Service Manual

PIONEER®
The Art of Entertainment

• KEH-P5700R/X1M/EW



ORDER NO.
CRT2171

MULTI-CD CONTROL HIGH POWER CASSETTE PLAYER WITH RDS TUNER

KEH-P5700R X1M/EW
KEH-P5730R X1M/EW

NOTE:

- See the separate manual CX-631(CRT1640) for the cassette mechanism description.
- The cassette mechanism assy employed in this model is one of 2L series.
- Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
"Dolby" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.
- This service manual does not describe the CD test mode.
For the operations in the CD test mode, refer to the CD player's Service Manual.

CONTENTS

1. SAFETY INFORMATION	2	7. GENERAL INFORMATION	38
2. EXPLODED VIEWS AND PARTS LIST	2	7.1 PARTS.....	38
3. SCHEMATIC DIAGRAM	10	7.1.1 IC.....	38
4. PCB CONNECTION DIAGRAM	20	7.1.2 DISPLAY	43
5. ELECTRICAL PARTS LIST	30	7.2 DISASSEMBLY	44
6. ADJUSTMENT	36	7.3 BLOCK DIAGRAM.....	45
		8. OPERATIONS AND SPECIFICATIONS	46

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153-8654, Japan
PIONEER ELECTRONICS SERVICE INC. P.O.Box 1760, Long Beach, CA 90801-1760 U.S.A.
PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE.LTD. 501 Orchard Road, #10-00, Wheelock Place, Singapore 238880

1. SAFETY INFORMATION

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

2. EXPLODED VIEWS AND PARTS LIST

2.1 PACKING




Fig. 1

NOTE:

- Parts marked by "*" and ⊗ can not be supplied.
- Screws adjacent to ∇ mark on the product are used for disassembly.

● PACKING SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Cord Assy	CDE5497	9	Contain Box (KEH-P5700R/X1M/EW)	CHL3464
2	Accessory Assy	CEA1917		Contain Box (KEH-P5730R/X1M/EW)	CHL3465
3	Screw	CBA1304	10	Protector	CHP2021
4	Handle(x2)	CNC5395			
5	Bush	CNV3930	11	Protector	CHP2022
*	6 Polyethylene Bag	E36-615	12	Owner's Manual	CRD2589
	7 Polyethylene Bag	CEG-162	13	Owner's Manual	CRD2590
	8 Carton (KEH-P5700R/X1M/EW)	CHG3464	14	Owner's Manual	CRD2591
	Carton (KEH-P5730R/X1M/EW)	CHG3465	15	Installation Manual	CRD2592
			*	16 Passport	CRY1013
			*	17 Warranty Card	CRY1087
				18 Case Assy	CXB1063

● Owner's Manual, Installation Manual

Model	Part No.	Language
KEH-P5700R/X1M/EW	CRD2589	English, Spanish
KEH-P5730R/X1M/EW	CRD2590	German, French
	CRD2591	Italian, Dutch
	CRD2592	English, Spanish, German, French Italian, Dutch

2.2 EXTERIOR











Fig. 2

(1) EXTERIOR SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Screw	BSZ26P050FMC	41	Button(▲,▼,◀,▶)	See Contrast table(2)
2	Screw	BSZ30P060FMC	42	Button(SOURCE)	CAC5433
3	Cord Assy	CDE5497	43	Button(+,-)	See Contrast table(2)
4	Cap	CKX-003	44	Button(BAND,F,A)	CAC5437
5	Screw	CBA1304	45	Button(TA/PTY,P, )	CAC5438
6	Handle	CNC5395	46	Button(1,2,3,4,5,6)	See Contrast table(2)
7	Bush	CNV3930	47	Button(D)	CAC5441
8	Fuse	CEK1136	48	Spring	CBH2103
9	Case	CNB2283	49	Spacer	CNM5572
10	Holder Unit	CXB2687	50	Sheet	CNM5897
11	Screw	BMZ30P100FMC	51	Cover	See Contrast table(2)
12	Screw	BSZ30P055FUC	52	Lighting Conductor	CNV5195
13	Screw	BSZ30P060FMC	53	Keyboard Unit	See Contrast table(2)
14	Holder	CNC5704	54	LCD(LCD901)	See Contrast table(2)
15	Cushion	CNM4870	55	Connector(CN901)	CKS3580
16	Insulator	CNM5571	56	Holder	CNC7479
⊗ 17	Tuner Amp Unit	CWM5669	57	Sheet	CNM5726
18	Screw	BPZ26P080FMC	58	Sheet	CNM5727
19	Screw	BSZ26P080FMC	59	Sheet	CNM5728
20	Screw	BSZ26P140FMC	60	Lighting Conductor	CNV5196
21	Cord(CN603)	CDE5327	61	Housing	CNV5197
22	FM/AM Tuner Unit	CWE1466	62	Connector	CNV5205
23	Holder	CNC6554	63	Grille Unit	See Contrast table(2)
24	Pin Jack(CN301)	CKB1028	64	Button	CAC4836
25	Plug(CN951)	CKM1270	65	Spring	CBH1834
26	Connector(CN751)	CKS3408	66	Spring	CBH1835
27	Connector(CN602)	CKS3568	67	Spring	CBH1996
28	Connector(CN601)	CKS3581	68	Bracket	CNC6135
29	Antenna Jack(CN402)	CKX1056	69	Bracket	CNC6791
30	Panel	CNB2256	70	Arm	CNV4692
31	Holder	CNC5399	71	Arm	CNV4693
32	Holder	CNC6531	72	Arm	CNV4728
33	Holder	CNC6674	73	Panel Unit	See Contrast table(2)
34	Holder	CNC6845	74	Door	CAT1930
35	Heat Sink	CNR1426	75	Spring	CBH1838
36	Chassis Unit	See Contrast table(2)	76	Screw	IMS20P030FZK
37	Case Assy	CXB1063	77	Cassette Mechanism Module	EXK3615
38	Detach Grille Assy	See Contrast table(2)	78	Transistor(Q951)	2SD2396
39	Screw	BPZ20P100FZK	79	IC(IC301)	TDA7384
40	Button()	See Contrast table(2)	80	LED(D903 — 905)	NSPWF50SB

(2) CONTRAST TABLE

KEH-P5700R/X1M/EW and KEH-P5730R/X1M/EW are constructed the same except for the following:

Mark No.	Symbol and Description	Part No.	
		KEH-P5700R/X1M/EW	KEH-P5730R/X1M/EW
36	Chassis Unit	CXB2025	CXB2346
38	Detach Grille Assy	CXB2440	CXB2305
40	Button()	CAC5430	CAC5514
41	Button( ,  ,  , )	CAC5431	CAC5515
43	Button(+,-)	CAC5435	CAC5516
46	Button(1,2,3,4,5,6)	CAC5439	CAC5517
51	Cover	CNS4775	CNS4858
53	Keyboard Unit	CWM5802	CWM5670
54	LCD(LCD901)	CAW1457	CAW1478
63	Grille Unit	CXB2460	CXB2461
73	Panel Unit	CXB2349	CXB2350

● CASSETTE MECHANISM MODULE SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Screw	BSZ20P040FMC	31	Gear	ENV1347
2	Washer	CBF1037	32	Collar	ENV1508
3	Washer	CBF1038	33	Gear	ENV1350
4	Washer	CBG1003	34	Flywheel	ENV1529
5	Deck Unit	EWM1010	35	Worm Gear	ENV1439
6	Screw	EBA1028	36	Worm Wheel	ENV1440
7	Screw	EBA1037	37	Gear	ENR1028
8	Spring	EBH1531	38	Lever	ENV1442
9	Spring	EBH1575	39	Arm	ENV1525
10	Plug(CN251)	CKS3540	40	Gathering P.C.Board	ENX1037
11	Spring	EBH1515	41	Gathering P.C.Board	ENX1042
12	Spring	EBH1587	42	Switch(S1,S2)	ESG1004
13	Spring	EBH1517	43	Motor Unit(M2)	EXA1485
14	Spring	EBH1518	44	Chassis Unit	EXA1511
15	Spring	EBH1519	45	Pinch Holder	ENV1485
16	Spring	EBH1537	46	Pinch Holder	ENV1486
17	Cord	EDD1020	47	Reel Unit	EXA1543
18	Photo-interrupter(EGN2,3)	EGN1006	48	Head Base Unit	EXA1457
19	Photo-interrupter(EGN1)	EGN1005	49	Lever Unit	EXA1438
20	Roller	ENR1031	50	Gear Unit	EXA1545
21	Shaft	ELA1373	51	Frame Unit	EXA1458
22	Pinch Roller	ENV1518	52	Lever Unit	EXA1439
23	Arm	ENC1489	53	Head Assy(HD1)	EXA1506
24	Arm	ENC1397	54	Motor Unit(M1)	EXA1544
25	Guide	ENC1481	55	Washer	HBF-179
26	Holder	ENC1417	56	Screw	BMZ20P022FMC
27	Lever	ENC1448	57	Spring	EBH1545
28	Arm	ENC1488	58	Washer	YE20FUC
* 29	Motor	EXM1031	59	Pinch Holder Unit	EXA1529
30	Belt	ENT1027	60	Pinch Holder Unit	EXA1528

A-b





Fig. 4








Fig. 5

A-a

A-b





NOTE :
- Symbol indicates a resistor.
- No differentiation is made between chip resistors and discrete resistors.
- Symbol indicates a capacitor.
- No differentiation is made between chip capacitors and discrete capacitors.

The Δmark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

A-a A-b

Fig. 6


A-b

3.2 FM/AM TUNER UNIT

A

B

FM/AM TUNER UNIT



B

3

4



TEST TAPE
NCT-150
(400Hz, 200nWb/m)





Fig. 8

4. PCB CONNECTION DIAGRAM


4.1 TUNER AMP UNIT

NOTE FOR PCB DIAGRAMS

1. The parts mounted on this PCB include all necessary parts for several destination.
For further information for respective destinations, be sure to check with the schematic diagram.
2. Viewpoint of PCB diagrams



A TUNER AMP UNIT



SIDE A

SY





Fig. 9

A

A TUNER AMP UNIT



IC, Q

SIDE B

A

Q207

Q208 Q610

IC752

Q751

Q752

IC951 Q601

Q901 Q902

IC401 Q602

Q401 Q202

IC602

Q957 Q958

Q954

Q960 Q605

Q959 Q206

Q701 Q962

Q963

Q301

IC201

IC601

Q706

Q209

IC702

Q702

IC701 Q703

Q704

B

C

D




Fig. 10

A



C

D

4.4 CASSETTE MECHANISM MODULE

D DECK UNIT

SIDE A




Fig. 15

D DECK UNIT

SIDE B




Fig. 16

E PCB UNIT

SIDE A




Fig. 17

E PCB UNIT

SIDE B




Fig. 18

F REEL PCB




Fig. 19

5. ELECTRICAL PARTS LIST

NOTE:

- Parts whose parts numbers are omitted are subject to being not supplied.
- The part numbers shown below indicate chip components.

Chip Resistor
RS1/○S○○○○J,RS1/○○S○○○○J
Chip Capacitor (except for CQS.....)
CKS....., CCS....., CSZS.....

====Circuit Symbol and No.==Part Name		Part No.	====Circuit Symbol and No.==Part Name		Part No.
<div><div>B</div><div>Unit Number : CWE1466 Unit Name : FM/AM Tuner Unit</div></div>			R	8	RS1/16S332J
MISCELLANEOUS			R	9	RS1/16S473J
IC	1	IC	R	10	RS1/16S223J
IC	2	IC	R	11	RS1/16S124J
Q	1	Transistor	R	13	RS1/16S563J
Q	2	Transistor	R	15	RS1/16S271J
Q	3	FET	R	16	RS1/16S104J
			R	17	RS1/16S332J
			R	18	RS1/16S332J
			R	31	RS1/16S470J
Q	31	Transistor			
Q	154	Transistor	R	32	RS1/16S822J
Q	165	Transistor	R	33	RS1/16S822J
Q	201	FET	R	34	RS1/16S331J
Q	202	Transistor	R	35	RS1/16S331J
			R	51	RS1/16S271J
Q	203	Transistor			
D	4	Diode	R	52	RS1/16S560J
D	5	Diode	R	55	RS1/16S102J
D	6	Diode	R	56	RS1/16S823J
D	7	Diode	R	61	RS1/16S392J
			R	62	RS1/16S393J
D	8	Diode			
D	201	Diode	R	101	RS1/16S272J
D	202	Diode	R	102	RS1/16S682J
D	231	Diode	R	103	RS1/16S333J
L	2	Coil	R	104	RS1/16S334J
			R	105	RS1/16S683J
L	3	Inductor			
L	4	Coil	R	107	RS1/16S222J
L	5	Coil	R	151	RS1/16S222J
L	6	Inductor	R	152	RS1/16S393J
L	51	Ferri-Inductor	R	154	RS1/16S104J
			R	155	RS1/16S273J
L	201	Ferri-Inductor			
L	202	Ferri-Inductor	R	156	RS1/16S243J
L	203	Inductor	R	157	RS1/16S203J
L	208	Inductor	R	160	RS1/16S222J
L	231	Inductor	R	161	RS1/16S563J
			R	162	RS1/16S105J
T	31	Coil			
T	51	Coil	R	163	RS1/16S222J
TC	1	Capacitor	R	202	RS1/16S223J
CF	51	Ceramic Filter	R	203	RS1/16S225J
CF	52	Ceramic Filter	R	204	RS1/16S103J
			R	206	RS1/16S220J
CF	53	Ceramic Filter			
CF	232	Ceramic Filter	R	207	RS1/16S101J
X	151	Resonator 920.5kHz	R	208	RS1/16S102J
X	231	Crystal Resonator 10.26MHz	R	209	RS1/16S471J
VR	154	Semi-fixed 150kΩ(B)	R	214	RS1/16S822J
			R	215	RS1/16S822J
AR	1	Capacitor with Discharge Gap			
RESISTORS			R	217	RS1/16S102J
			R	231	RS1/16S272J
			R	232	RS1/16S473J
R	1	RS1/16S0R0J	R	237	RS1/16S103J
R	4	RS1/16S154J	R	238	RS1/16S104J
R	5	RS1/16S391J			
R	6	RS1/16S223J	R	239	RS1/16S104J
R	7	RS1/16S123J	R	240	RS1/16S332J
			R	241	RS1/16S202J
			R	243	RS1/16S123J
			R	244	RS1/16S103J

A

Unit Number : CWM5669
Unit Name : Tuner Amp Unit

MISCELLANEOUS

IC	201	IC	SN761027DL
IC	301	IC	TDA7384
IC	401	IC	PM2007A
IC	601	IC	PD4914A
IC	604	IC	S-80734AN
IC	701	IC	PM4006B
IC	702	IC	TA75S393F
IC	751	IC	TA2050S
IC	752	IC	CA0008AM
IC	951	IC	TPD1018F
Q	203	Transistor	DTC114TS
Q	204	Transistor	DTC114TS
Q	205	Transistor	DTA124ES
Q	206	Transistor	DTA124EK
Q	207	Transistor	DTC143TK
Q	208	Transistor	DTC143TK
Q	209	Transistor	DTC114EK
Q	301	Transistor	DTC124EK
Q	302	Transistor	2SC1740S
Q	401	Transistor	2SC2412K
Q	601	Transistor	2SC2412K
Q	602	Transistor	2SC2412K
Q	604	Transistor	2SA933S
Q	605	Transistor	DTC124EK
Q	606	Transistor	2SC1740S
Q	609	Transistor	2SA933S
Q	701	Transistor	DTC143TK
Q	702	Transistor	DTC114EK
Q	703	Transistor	2SD1757K
Q	704	Transistor	2SD1757K
Q	706	Transistor	2SC2412K
Q	707	Transistor	DTC143TS
Q	708	Transistor	DTC143TS
Q	751	Transistor	2SA1037K
Q	752	Transistor	DTC114EK
Q	951	Transistor	2SD2396
Q	952	Transistor	2SD2037
Q	953	Transistor	2SA933S
Q	954	Transistor	DTC114EK
Q	955	Transistor	2SA1674

KEH-P5700R,P5730R

====Circuit Symbol and No.==Part Name	Part No.	====Circuit Symbol and No.==Part Name	Part No.
Q 956 Transistor	2SA1048	R 303	RS1/10S153J
Q 957 Transistor	DTC114TK	R 304	RS1/10S103J
Q 958 Transistor	DTC114TK	R 305	RS1/10S152J
Q 959 Transistor	2SC2412K	R 306	RS1/10S101J
Q 960 Transistor	DTC114TK	R 307	RS1/8S562J
Q 961 Transistor	2SB1243	R 308	RS1/8S223J
D 301 Diode	MA152WK	R 401	RS1/10S272J
D 403 Diode	1SS270	R 402	RS1/10S272J
D 601 Diode	HZS7L(C2)	R 403	RS1/10S102J
D 602 Diode	HZS7L(A1)	R 404	RS1/10S222J
D 603 Diode	1SS270	R 405	RS1/10S222J
D 614 LED	BR4361F	R 407	RS1/10S0R0J
D 615 Diode	1SS270	R 408	RS1/10S562J
D 616 Diode	1SS270	R 409	RS1/10S222J
D 617 Diode	1SS270	R 410	RS1/10S102J
D 618 Diode	1SS270	R 411	RS1/10S682J
D 619 Diode	1SS270	R 412	RS1/10S472J
D 620 Diode	1SS270	R 413	RS1/10S222J
D 621 Diode	1SS270	R 414	RS1/10S682J
D 622 Diode	HZS7L(A1)	R 415	RS1/10S472J
D 701 Diode	1SS270	R 416	RS1/10S561J
D 951 Diode	1SR139-400	R 417	RS1/10S103J
D 952 Diode	1SR139-400	R 418	RS1/10S152J
D 953 Diode	1SR139-400	R 419	RS1/10S222J
D 954 Diode	1SR139-400	R 420	RS1/10S392J
D 955 Diode	1SR139-400	R 421	RS1/10S272J
D 956 Diode	HZS6L(B2)	R 422	RS1/10S392J
D 957 Diode	HZS9L(B3)	R 423	RS1/10S473J
D 959 Diode	HZS9L(A2)	R 424	RS1/10S473J
L 401 Ferri-Inductor	LAU2R2K	R 425	RS1/10S472J
L 403 Ferri-Inductor	LAU2R2K	R 426	RS1/8S473J
L 601 Ferri-Inductor	LAU2R2K	R 427	RD1/4PU102J
L 602 Ferri-Inductor	LAU2R2K	R 428	RD1/4PU102J
L 603 Ferri-Inductor	LAU2R2K	R 429	RD1/4PU102J
L 701 Ferri-Inductor	LAU101K	R 430	RD1/4PU102J
L 751 Ferri-Inductor	LAU2R2K	R 431	RS1/10S472J
L 951 Choke Coil 600μH	CTH1168	R 433	RS1/10S104J
X 401 Crystal Resonator 7.200MHz	CSS1379	R 434	RD1/4PU222J
X 631 Ceramic Resonator 6.29MHz	CSS1310	R 435	RS1/10S103J
X 701 Crystal Resonator 4.332MHz	CSS1056	R 436	RS1/10S393J
VR 701 Semi-fixed 22kΩ(B) FM/AM Tuner Unit	CCP1321	R 440	RS1/8S0R0J
	CWE1466	R 448	RS1/10S102J
		R 449	RS1/8S0R0J
		R 450	RS1/10S680J
		R 451	RS1/8S0R0J
RESISTORS			
R 201	RS1/10S821J		
R 202	RS1/10S821J	R 601	RS1/10S223J
R 203	RS1/10S104J	R 602	RS1/8S473J
R 204	RS1/10S104J	R 603	RS1/10S473J
R 205	RS1/8S563J	R 604	RS1/10S223J
		R 605	RS1/10S473J
R 206	RS1/10S563J		
R 207	RS1/10S152J	R 606	RS1/10S473J
R 208	RS1/10S152J	R 607	RS1/10S0R0J
R 209	RS1/10S272J	R 609	RS1/10S0R0J
R 210	RS1/10S272J	R 611	RS1/10S751J
		R 612	RS1/10S103J
R 211	RS1/8S151J		
R 212	RS1/10S151J	R 613	RS1/10S223J
R 213	RS1/10S221J	R 614	RS1/10S223J
R 214	RS1/10S221J	R 615	RS1/10S223J
R 215	RS1/10S104J	R 616	RS1/10S272J
		R 617	RS1/10S473J
R 216	RS1/10S104J		
R 217	RS1/10S103J	R 629	RS1/10S0R0J
R 218	RS1/8S102J	R 631	RS1/10S473J
R 223	RS1/10S473J	R 633	RS1/10S473J
R 224	RS1/10S473J	R 637	RD1/4PU102J
		R 638	RS1/10S124J
R 228	RS1/10S123J		
R 229	RS1/10S392J	R 639	RD1/4PU222J
R 230	RS1/10S392J	R 640	RS1/10S223J
R 301	RD1/4PU103J	R 641	RD1/4PU222J
R 302	RS1/10S221J	R 642	RS1/8S103J
		R 643	RS1/8S222J

====Circuit Symbol and No.==Part Name		Part No.	====Circuit Symbol and No.==Part Name		Part No.
R	644	RD1/4PU222J	R	759	RS1/10S473J
R	645	RD1/4PU103J	R	760	RS1/10S473J
R	646	RS1/8S222J	R	761	RS1/10S102J
R	647	RS1/8S222J	R	762	RS1/10S101J
R	648	RS1/10S222J	R	763	RS1/10S101J
R	649	RS1/10S222J	R	764	RS1/10S620J
R	650	RD1/4PU222J	R	765	RS1/10S223J
R	651	RD1/4PU222J	R	766	RS1/10S472J
R	652	RD1/4PU222J	R	767	RS1/10S222J
R	653	RS1/10S222J	R	768	RS1/10S0R0J
R	654	RS1/10S473J	R	951	RS1/10S473J
R	655	RS1/10S473J	R	952	RD1/4PU102J
R	656	RS1/10S473J	R	953	RD1/4PU471J
R	657	RS1/10S473J	R	954	RD1/4PU101J
R	658	RS1/10S103J	R	955	RS1/10S472J
R	659	RS1/10S392J	R	956	RS1/10S473J
R	660	RS1/10S472J	R	957	RS1/10S102J
R	661	RD1/4PU472J	R	958	RS1/10S473J
R	662	RS1/10S222J	R	959	RS1/10S102J
R	663	RS1/8S222J	R	960	RS1/8S103J
R	664	RD1/4PU102J	R	961	RS1/8S1R0J
R	665	RD1/4PU102J	R	962	RS1/10S103J
R	667	RS1/10S102J	R	963	RS1/10S223J
R	695	RS1/8S472J	R	964	RS1/10S152J
R	702	RS1/10S333J	R	967	RS1/10S473J
R	703	RS1/10S0R0J	R	968	RS1/10S102J
R	704	RD1/4PU102J	R	973	RS1/10S0R0J
R	705	RD1/4PU102J			
R	706	RD1/4PU102J		CAPACITORS	
R	707	RD1/4PU102J			
R	708	RD1/4PU102J	C	201	CEJA2R2M50
R	709	RD1/4PU102J	C	202	CEJA2R2M50
R	710	RS1/10S222J	C	203	CEJA1R0M50
R	711	RS1/10S222J	C	204	CEJA1R0M50
R	712	RS1/10S681J	C	205	CEJA4R7M35
R	713	RS1/10S684J	C	206	CEJA4R7M35
R	714	RS1/10S562J	C	207	CEJA100M16
R	715	RS1/10S562J	C	208	CEJA100M16
R	716	RS1/10S104J	C	209	CKSQYB822K50
R	717	RS1/10S104J	C	210	CKSQYB822K50
R	718	RS1/10S103J	C	211	CEJA1R0M50
R	719	RS1/10S473J	C	212	CEJA1R0M50
R	720	RD1/4PU102J	C	213	CKSQYB183K25
R	721	RD1/4PU102J	C	214	CKSQYB183K25
R	722	RS1/10S562J	C	215	CKSQYB102K50
R	723	RS1/10S105J	C	216	CKSQYB102K50
R	724	RD1/4PU0R0J	C	217	CEJA2R2M50
R	725	RS1/10S224J	C	218	CEJA2R2M50
R	726	RS1/10S224J	C	219	CKSQYB333K25
R	727	RS1/10S222J	C	220	CKSQYB333K25
R	728	RS1/10S222J	C	221	CEJA220M10
R	729	RS1/10S223J	C	222	CEJA220M10
R	730	RS1/10S223J	C	223	CKSQYF104Z25
R	731	RS1/10S224J	C	225	CKSQYB473K16
R	732	RD1/4PU152J	C	226	CKSQYB102K50
R	733	RD1/4PU102J	C	227	CEJA2R2M50
R	734	RS1/10S0R0J	C	228	CEJA2R2M50
R	751	RS1/10S181J	C	229	CEJA2R2M50
R	752	RS1/10S181J	C	230	CEJA2R2M50
R	753	RS1/10S223J	C	236	CKSQYB473K16
R	754	RS1/10S223J	C	309	3300μF/16V
R	755	RS1/10S102J	C	310	CCH1018
R	756	RS1/10S102J	C	311	CKSQYB104K16
R	757	RS1/10S102J	C	312	CKSQYB224K16
R	758	RS1/8S102J	C	313	CKSQYB224K16

====Circuit Symbol and No.==Part Name	Part No.	====Circuit Symbol and No.==Part Name	Part No.
C 314	CKSQYB224K16	C 724	CEJA2R2M50
C 315	CEJA100M16	C 751	CEJA1R0M50
C 316	CKSQYB224K16	C 752	CEJA1R0M50
C 317	CEJA1R0M50	C 753	CEJA1R0M50
C 318	CEJA330M10	C 754	CEJA1R0M50
C 401	CKSQYB223K25	C 755	CEJA100M16
C 402	CKSYB273K25	C 756	CEJA100M16
C 406	CCSOSL101J50	C 757	CKSQYB102K50
C 407	CKSQYB102K50	C 758	CKSQYB104K16
C 408	CEJA220M16	C 951	470μF/16V CCH1183
C 409	CKSQYB103K25	C 952	CEJA470M10
C 410	CEJA220M6R3	C 953	CEAS101M10
C 411	CEJA220M16	C 954	CKSQYB103K25
C 412	CKSQYB103K25	C 956	CKSQYB103K25
C 413	CKSQYB103K25	C 957	CKSQYB103K25
C 414	4.7μF/16V CCH1250	C 958	CEAS101M10
C 415	CKSQYB103K25	C 959	CKSYB103K50
C 416	CKLSR473K16	C 960	CKSQYB472K50
C 418	CKSQYB103K25		
C 420	CKSQYB103K25		
C 421	CKSQYB103K25		
C 422	CEJA220M6R3		
C 423	CKSQYB473K16		
C 424	4.7μF/16V CCH1250		
C 425	CKSQYB103K25		
C 426	CEJAR47M50		
C 428	CKSQYB103K25		
C 429	CCSQCH150J50		
C 430	CCSQCH150J50		
C 431	CCSQSL101J50		
C 432	CKSQYB103K25		
C 439	CKSQYB223K25		
C 440	CKSQYB223K25		
C 441	CKSQYB223K25		
C 442	CKSQYB102K50		
C 602	CKSQYB103K25		
C 606	CEJA100M16		
C 607	CCSQSL101J50		
C 612	CEAL2R2M50		
C 613	CKSYB102K50		
C 614	CCSQSL101J50		
C 615	CEJA4R7M35		
C 616	CKSQYB103K25		
C 619	CKSQYB473K16		
C 622	CEJA220M10		
C 624	CKSYB102K50		
C 701	CKSQYF104Z25		
C 702	CKSQYB222K50		
C 703	CKSQYB104K16		
C 704	CKSYB105K16		
C 705	CKSYB104K16		
C 706	CKSQYB472K50		
C 707	CEJA4R7M35		
C 708	CKSQYB104K16		
C 709	CCSQCH220J50		
C 710	CCSQCH220J50		
C 711	CKSQYB104K16		
C 712	CEJA4R7M35		
C 713	CKSQYB223K25		
C 714	CEJA4R7M35		
C 715	CKSQYB103K25		
C 716	CKSQYB103K25		
C 721	CKSQYB471K50		
C 722	CKSQYB223K25		
C 723	CEAL2R2M50		

D Unit Number : EWM1016
Unit Name : Deck Unit

MISCELLANEOUS

IC 251	IC	CXA2560Q
IC 351	IC	PA2020A
Q 351	Transistor	2SB1260
Q 352	Transistor	2SC4102
D 351	Diode	1SS355
VR 301	Semi-fixed 33kΩ(B)	CCP1280
VR 302	Semi-fixed 33kΩ(B)	CCP1280

RESISTORS

R 255	RS1/16S221J
R 256	RS1/16S221J
R 257	RS1/16S102J
R 258	RS1/16S102J
R 271	RS1/16S102J
R 272	RS1/16S102J
R 273	RS1/16S102J
R 281	RS1/8S0R0J
R 282	RS1/8S0R0J
R 283	RS1/8S0R0J
R 284	RS1/8S0R0J
R 285	RS1/16S0R0J
R 286	RS1/16S0R0J
R 287	RS1/8S0R0J
R 290	RS1/8S0R0J
R 301	RS1/16S183J
R 322	RS1/16S102J
R 351	RS1/16S102J
R 352	RS1/16S102J
R 353	RS1/16S102J
R 354	RS1/16S102J
R 355	RS1/10S274J
R 356	RS1/10S202J
R 357	RS1/10S472J
R 358	RS1/10S103J
R 359	RS1/10S103J
R 360	RS1/10S102J
R 361	RS1/10S622J
R 362	RS1/8S181J
R 373	RS1/8S0R0J
R 374	RS1/8S0R0J
R 375	RS1/8S0R0J
R 401	RS1/16S472J
R 402	RS1/16S163J
R 403	RS1/16S823J

====Circuit Symbol and No.==Part Name

Part No.

CAPACITORS

C	251	CKSRYB331K50
C	252	CKSRYB331K50
C	253	CKSRYB331K50
C	254	CKSRYB331K50
C	255	CKSRYB103K25
C	256	CKSRYB103K25
C	272	CKSQYB104K16
C	273	CEJA220M16
C	301	CKSYB104K50
C	302	CKSYB104K50
C	309	CKSQYB104K16
C	310	CKSQYB104K16
C	313	CCSQCH101K50
C	351	CKSYB224K25
C	352	CKSQYB392K50
C	353	CKSQYB103K50
C	354	CKSQYB103K50
C	355	CKSYB104K50
C	356	CKSQYB103K50
C	401	CKSQYB334K16
C	402	CKSQYB472K50
C	403	CKSQYB683K16



Unit Number : CWM5802(KEH-P5700R/X1M/EW)

Unit Number : CWM5670(KEH-P5730R/X1M/EW)

Unit Name : Keyboard Unit

MISCELLANEOUS

IC	901	IC	PD6246A
IC	902	IC	RS-140
Q	901	Transistor	2SC2412K
D	901	Chip Diode	MA151WK
D	902	Diode	MA151WA
D	903	LED	NSPWF50SB
D	904	LED	NSPWF50SB
D	905	LED	NSPWF50SB
D	906	LED	See Contrast table
D	907	LED	See Contrast table
D	908	LED	See Contrast table
D	909	LED	See Contrast table
D	910	LED	See Contrast table
L	901	Inductor	LCTA101J3225
X	901	Ceramic Resonator 4.97MHz	CSS1312
S	901	Switch	CSG1043
S	902	Switch	CSG1043
S	903	Switch	CSG1043
S	904	Switch	CSG1041
S	905	Switch	See Contrast table
S	906	Switch	See Contrast table
S	907	Switch	CSG1041
S	908	Switch	See Contrast table
S	909	Switch	CSG1041
S	910	Switch	See Contrast table
S	911	Switch	See Contrast table
S	912	Switch	See Contrast table
S	913	Switch	See Contrast table
S	914	Switch	See Contrast table
S	915	Switch	See Contrast table
S	916	Switch	See Contrast table
S	917	Switch	See Contrast table
S	918	Switch	See Contrast table
S	919	Switch	See Contrast table
S	920	Switch	See Contrast table

====Circuit Symbol and No.==Part Name

Part No.

S	921	Switch	See Contrast table
IL	901	Lamp 14V 40mA	See Contrast table
LCD	901	LCD	See Contrast table

RESISTORS

R	901	RS1/10S222J
R	902	RS1/10S222J
R	903	RS1/10S472J
R	904	RS1/10S121J
R	905	RS1/10S2R2J
R	906	RS1/10S470J
R	907	RS1/10S470J
R	908	RS1/4S511J
R	909	RS1/4S751J
R	910	RS1/4S391J
R	911	RS1/4S391J
R	912	RS1/4S391J
R	913	RS1/4S391J
R	914	RS1/4S391J
R	915	RS1/4S391J
R	916	RS1/4S391J
R	917	RS1/4S391J
R	918	RS1/10S472J
R	919	RS1/4S391J

CAPACITORS

C	901	CSZSR100M6R3
C	902	CKSQYF104Z50
C	903	CSZSR100M6R3
C	904	CKSQYB103K25
C	905	CKSQYB103K25
C	906	CKSQYB103K25
C	907	CKSQYF104Z50
C	908	CKSQYF104Z50
C	909	CKSQYF104Z50

CONTRAST TABLE of KEYBOARD UNIT

KEH-P5700R/X1M/EW and KEH-P5730/X1M/EW

have the same construction except for the following:

Symbol and Description		Part No.	
		KEH-P5700R/X1M/EW	KEH-P5730R/X1M/EW
LCD	901 LCD	CAW1457	CAW1478
IL	901 Lamp	CEL1558(14V 40mA)	CEL1508(14V 40mA)
D	906 - 910 Diode	CL170PGCD	CL170DCD
S	905,908,916 Switch	CSG1084	CSG1078
S	906,910,915 Switch	CSG1085	CSG1079
S	911 - 914 Switch	CSG1086	CSG1080
S	917,919,921 Switch	CSG1085	CSG1079
S	918,920 Switch	CSG1084	CSG1078



Unit Number :

Unit Name : PCB Unit

S	1	Switch (Load)	ESG1004
S	2	Switch (70μS)	ESG1004
EGN	1	Photo-Interrupter	EGN1005



Unit Number :

Unit Name : Reel PCB

EGN	2	Photo-Interrupter	EGN1006
EGN	3	Photo-Interrupter	EGN1006

Miscellaneous Parts List

M	1	Motor Unit (Main)	EXA1544
M	2	Motor Unit (Sub)	EXA1485
HD	1	Head Assy	EXA1506

6. ADJUSTMENT

● Connection Diagram




Fig. 20

FM ADJUSTMENT

Modulation M: MONO MOD., 400Hz 30%(22.5kHz Dev.) or 400Hz 100%(75kHz Dev.)

S: STEREO MOD., 1kHz, L or R=30%(20.25kHz+7.5kHz Dev.)

S2: STEREO MOD., 400Hz, L or R=60%(40.50kHz+7.5kHz Dev.)

NOTE: Before proceeding to further adjustments after switching power ON, let the tuner run for ten minutes to allow the circuits to stabilize.

	No.	FM SSG		Displayed Frequency(MHz)	Adjustment Point	Adjustment Method (Switch Position)
		Frequency(MHz)	Level(dBf)			
TUN Volt	1	108.0	L5	DC V Meter(1) : 6V
IF	2	98.1 M	60	98.1	T51	Center Meter : 0
ANT Coil	3	98.1 M	5	98.1	L2	mV Meter(1) : Maximum
RF Coil	4	98.1 M	5	98.1	L4	mV Meter(1) : Maximum
Image	5	129.3 M	60—80	107.9	TC1	mV Meter(1) : Minimum
IFT	6	98.1 M	5	98.1	T31	mV Meter(1) : Maximum (STEREO MODE)
ARC	7	98.1 S	40	98.1	VR154	mV Meter(1) : Separation 5dB (STEREO MODE)

RDS SL ADJUSTMENT

	No.	FM SSG		Displayed Frequency(MHz)	Adjustment Point	Adjustment Method (Switch Position)
		Frequency(MHz)	Level(dBf)			
	1	104.0 S2	35	104.0	VR701	DC V Meter(2) : 1.75V+0.05V,-0.35V

DOLBY B NR ADJUSTMENT


No.	Test Tape	Adjustment Point	Adjustment Method (Switch Position)
1	NCT-150 (400Hz,200nwb/m)	VR301(Lch),VR302(Rch)	mV Meter(2) : -6dBs±1.0dB (DOLBY NR Switch : OFF)

7. GENERAL INFORMATION


7.1 PARTS

7.1.1 IC


TDA7384




PM2007A



PM4006B



CXA2560Q




● Pin Functions (PD4914A)

Pin No.	Pin Name	I/O	Format	Function and Operation
1	ASENBO	O	C	Slave power supply control output
2	NC			Not used
3	ADPW	O	C	A/D converter power
4	AVSS			A/D GND
5	FIEOUT	O	C	FIE ON/OFF control output
6	ST	I		FM stereo input
7	AVREF1			(Connect to VDD)
8	KYDT	I		Key data input
9	DPDT	O	C	Display data output
10	SWVDD	O	C	Key board unit power supply control output
11	TUNPD1	I		PLL IC data input
12	TUNPD0	O	C	PLL IC data output
13	TUNPCK	O	C	PLL IC clock
14	TUNPCE	O	C	PLL IC chip enable
15	CURRRQ	O	C	Tuner voltage FIX output
16-19	NC			Not used
20	DRELAY			Not used
21	EORR			Not used
22	EVST	O	C	Electric volume strobe output
23	EVCK	O	C	Electric volume serial clock output
24	EVDT	O	C	Electric volume serial data output
25	LCDPW			Not used
26	DRSYS	O	C	Door system select output
27	DRSENS	I		Door open/close sense input
28	ILPW	O	C	Illumination power
29	FM	O	C	FM power control output
30	AM	O	C	AM power control output
31	NR	O	C	NR output
32	CM	O	C	Cassette mechanism capstan motor control output
33	VSS			GND
34	SC2	O	C	Cassette mechanism sub motor control output
35	SC1	O	C	Cassette mechanism sub motor control output
36	MS	I		Cassette mechanism MS sense input
37	NC			Not used
38	MTL	I		Cassette mechanism tape select input
39	DLED	O	N	Alarm LED output
40	N/R	O	C	Normal reverse output
41	PLAY	O	C	Tape MS filter select output
42	LOADSW	I		Tape loading input
43	POS	I		Cassette mechanism position sense input
44	RES	I		Cassette mechanism reverse end sense input
45	PEE	O	C	Beep tone output
46	NES	I		Cassette mechanism forward end sense input
47	RDS57K	I		57kHzBP-OUT sense input
48	STBY	O		Stand-by output
49	SK	I		SK signal input
50	DRST	O	C	Reset output
51	TMUTE	O	C	Tuner mute output
52	MDSENS	I		Modulation detect input
53	SD	I		SD input
54	MUTE	O	C	System mute output
55	SYSPW	O	C	System power supply control output
56	TX	O	C	IP BUS data output
57	RX	I		IP BUS data input
58	RDSLK	I		RDS LK signal input
59	RDT	I		RDS demodulation data input
60	RESET	I		Reset input

Pin No.	Pin Name	I/O	Format	Function and Operation
61	LDET	I		PLL lock sense input
62	RCK	I		RDS demodulation clock input
63	DSNS	I		Grille detach sense
64	ISENS			Not used
65	ASENS	I		ACC power sense input
66	BSNS	I		Back up power sense input
67	CLKIN	I		Clock input
68	VDD			Power supply
69	X2			Oscillator output
70	X1			Oscillator input
71	IC			GND
72	NC			Not used
73	TESTIN	I		Test program mode input
74	AVDD	I		A/D converter analogue power
75	AVREF0	I		A/D converter standard voltage input
76	SL	I		Signal level input
77	CL	I		Synchronizing signal input of display data latch
78	NL	I		Noise level input
79	NC			Not used
80	ALMUTE	O	C	Mute output for Detach alarm

*PD4914A



IC's marked by* are MOS type.


Be careful in handling them because they are very liable to be damaged by electrostatic induction.

Format	Meaning
C	C MOS
N	N Channel open drain

● Pin Functions(PD6246A)

Pin No.	Pin Name	I/O	Function and Operation
1	VSS		GND
2	X1		Crystal oscillator connection pin
3	X0		Crystal oscillator connection pin
4	RST	I	System reset
5,6	MODE1,0		GND
7	DIM	O	Dimmer select output
8	SO	O	UART output
9	SI	I	UART input
10	REMIN	I	Remote control reception
11	RVER		Not used
12	NC		Not used
13-16	KDT4-1	I	Key data input
17-22	KST6-1	O	Key strobe output
23	VCC		5V
24-73	SEG49-0	O	LCD segment output
74-77	COM3-0	O	Common driver output
78-80	V3-1		LCD bias power supply

*PD6246A



7.1.2 DISPLAY

- CAW1457(KEH-P5700R/X1M/EW)
- CAW1478(KEH-P5730R/X1M/EW))




Fig. 21

7.2 DISASSEMBLY

● Removing the Case(not shown)

- 1.Remove the three screws.
- 2.Remove the Case.

● Removing the Cassette Mechanism Module (not shown)

- 1.Remove the four screws.
- 2.Disconnect the connector, and then removing the Cassette Mechanism Module.

● Removing the Detach Grille Assy(Fig.22)

- 1.Push the detach button.
- 2.Remove the Detach Grille Assy.

● Removing the Panel Unit(Fig.22)

- 1.Disengage the stopper at four locations indicated by white-arrows and then remove the Panel.
- 2.Disengage the stopper at two locations indicated by black-arrows.
- 3.Remove the Panel Unit.




Fig. 22

● Removing the Tuner Amp Unit(Fig.23)

- 1.Removing the two screws A, three screws B and screw C.
- 2.Unbend the tabs at four locations indicated by arrow until straight.
- 3.Remove the Tuner Amp Unit.




Fig. 23



8. OPERATIONS AND SPECIFICATIONS





Fig. 25

8.1. OPERATIONS

Basic Operation

Head Unit

Key Finder




To Listen to Music

The following explains the initial operations required before you can listen to music.

Note:

- Loading a cassette in this product.

1. Select the desired source (e.g. Tuner).



Head Unit

Each press of the SO button selects the desired source in the following order:

Tuner → Tape → Multi-CD player → AUX

Remote Controller

Each press of the button selects the desired source in the following order:

TUNER button : Tuner → OFF


TAPE button : Tape → OFF

CD button : Multi-CD player → OFF


Note:

- In the following cases, the sound source will not change:
 - No Multi-CD player is connected to this product.
 - No cassette tape is set in this product.
 - No magazine is set in the Multi-CD player.
 - AUX (external input) is set to OFF.

2. Raise or lower the volume.



3. Turn the source OFF.



Basic Operation of Tuner

This product's AF function can be switched ON and OFF. AF should be switched OFF for normal tuning operations.


Manual and Seek Tuning

- You can select the tuning method by changing the length of time you press the ◀▶ button.

Manual Tuning (step by step)	0.3 seconds or less
Seek Tuning (automatically)	0.3 – 2 seconds
Manual Tuning (continuously)	2 seconds or more

Note:

- "S" stereo indicator lights when a stereo station is selected.



Band

- F1 (FM1) → F2 (FM2)
- F3 (FM3) → MW/LW

Preset Tuning

- You can memorize broadcast stations in buttons 1 through 6 for easy, one-touch station recall.

Preset station recall	2 seconds or less
Broadcast station preset memory	2 seconds or more

Note:

- Up to 18 FM stations (6 in F1 (FM1), F2 (FM2) and F3 (FM3)) and 6 MW/LW stations can be stored in memory.
- You can also use the ▲ or ▼ buttons to recall broadcast stations memorized in buttons 1 through 6.

Basic Operation of Cassette Player

Fast Forward/Rewind and Music Search

- Each press of the ◀ button selects **Rewind** or **Rewind-Music Search**. REW (Rewind) → R-MS (Rewind-Music Search) → Normal Playback
- Each press of the ▶ button selects **Fast forward** or **Forward-Music Search**. FF (Fast forward) → F-MS (Forward-Music Search) → Normal Playback


Note:

- Fast forward/Rewind and Music Search can be canceled by pressing the ◀▶ button.

Cassette Loading Slot

Note:

- "METAL" appears on the display for 2 seconds when a metal or chrome tape is inserted. Nothing is displayed for a normal tape.



Eject

Note:

- The Tape function can be turned ON/OFF with the cassette tape remaining in this product.

Basic Operation of Multi-CD Player

This product can control one or more multi-CD players. (There are some types of Multi-CD players such as "CDX-P630S" which you cannot connect more than one.)

Switching the Multi-CD Player


Using a multiple connection adapter lets you connect up to three Multi-CD players.

M-CD 1 → M-CD 2 → M-CD 3
(Displayed for about 2 seconds.)

Track Search and Fast Forward/Reverse

- You can select between Track Search or Fast forward/Reverse by pressing the ◀/▶ button for a different length of time.

Track Search	0.5 seconds or less
Fast forward/Reverse	Continue pressing



Disc Number Search (for 6-Disc, 12-Disc types)

- You can select discs directly with the 1 to 6 buttons. Just press the number corresponding to the disc you want to listen to.

Note:

- When a 12-Disc Multi-CD Player is connected and you want to select disc 7 to 12, press the 1 to 6 buttons for 2 seconds or longer.

Disc Number Rough Search (for 50-Disc type only)

This handy function lets you select discs loaded in a 50-Disc Multi-CD Player using the 1 to 5 buttons. The 50 discs are divided into five blocks, with each of the 1 to 5 buttons assigned to a block.

- Select the desired block with the 1 to 5 button.

Note:

- After completing a rough search, use the ▲ and ▼ buttons to select a desired disc.

Displaying Disc Titles

- Press the DISPLAY button, to change the Disc Title display of the current disc.

Note:

- If you switch displays when disc titles have not been input, "NO TITLE" is displayed for about 8 seconds.
- Repeat the preceding operation to return to the normal display.

Note:

- The multi-CD player may perform a preparatory operation, such as verifying the presence of a disc or reading disc information, when the power is turned ON or a new disc is selected for playback. "READY" is displayed.
- When a magazine is loaded into a 50-Disc type Multi-CD Player, information on all the discs in the magazine is read.
- If you start playing a disc on a 50-Disc type Multi-CD Player before reading of information on all discs has been completed, reading of information stops part way through. This will prevent you from using a number of functions. (If you try and use these functions, "NOT READY" is displayed.)
- If this happens, reading of information begins again when you switch to a component other than the 50-Disc type Multi-CD Player.
- If the multi-CD player cannot operate properly, an error message such as "ERROR-14" is displayed. Refer to the multi-CD player owner's manual.
- If there are no discs in the multi-CD player magazine, "NO DISC" is displayed.
- "LOAD" will be displayed in the following cases:
 - * If the disc in the extra tray is selected.
 - * If the disc is moved from the extra tray to the magazine.

(Refer to the 50-Disc type multi-CD player owner's manual.)


Entering the Function Menu

The Function Menu lets you operate simple functions for each source.


Note:

- After entering the Function Menu, if you do not perform an operation within about 30 seconds, the Function Menu is automatically canceled.


1. Select the desired mode in the Function Menu.



2. Operate a mode. (e.g. Repeat Play)



3. Cancel the Function Menu.



8.2 SPECIFICATIONS

Specifications

General

Power source 14.4 V DC (10.8 – 15.1 V allowable)
 Grounding system Negative type
 Max. current consumption 8.5 A
 Dimensions
 (mounting size) 178 (W) × 50 (H) × 153 (D) mm
 (front face) 188 (W) × 58 (H) × 19 (D) mm
 Weight 1.2 kg

Amplifier

Maximum power output 35 W × 4
 Continuous power output 22 W × 4
 (DIN45324, +B = 14.4 V)
 Load impedance 4 Ω (4 – 8 Ω allowable)
 Preout output level/output impedance 500 mV/1 k Ω
 Tone controls
 (Bass) ± 12 dB (100 Hz)
 (Treble) ± 12 dB (10 kHz)
 Loudness contour +10 dB (100 Hz), +7 dB (10 kHz)
 (volume: -30 dB)

Cassette player

Tape Compact cassette tape (C-30 – C-90)
 Tape speed 4.76 cm/sec.(+0.14 cm/sec., -0.05 cm/sec.)
 Fast forward/rewinding time Approx. 100 sec. for C-60
 Wow & flutter 0.09% (WRMS)
 Frequency response Metal: 30 – 19,000 Hz (± 3 dB)
 Stereo separation 45 dB
 Signal-to-noise ratio
 Metal: Dolby B NR IN: 67 dB (IEC-A network)
 Dolby NR OUT: 61 dB (IEC-A network)

FM tuner

Frequency range 87.5 – 108 MHz
 Usable sensitivity
 11 dBf (1.0 μ V/75 Ω , mono, S/N: 30 dB)
 50 dB quieting sensitivity 16 dBf (1.7 μ V/75 Ω , mono)
 Signal-to-noise ratio 70 dB (IEC-A network)
 Distortion 0.3% (at 65 dBf, 1 kHz, stereo)
 Frequency response 30 – 15,000 Hz (± 3 dB)
 Stereo separation 40 dB (at 65 dBf, 1 kHz)

MW tuner

Frequency range 531 – 1,602 kHz
 Usable sensitivity 18 μ V (S/N: 20 dB)
 Selectivity 50 dB (± 9 kHz)

LW tuner

Frequency range 153 – 281 kHz
 Usable sensitivity 30 μ V (S/N: 20 dB)
 Selectivity 50 dB (± 9 kHz)

Note:

- Specifications and the design are subject to possible modification without notice due to improvements.

